


Storage Bench

Assembly Instructions - Please keep for future reference

496/1932



Dimensions

Width - 120cm

Depth - 40cm

Height - 39.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


- Regularly check and ensure that all bolts and fittings are tightened properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the
Customer Helpline: Argos = 0345 6400800


Please check you have all the panels listed below




1 Front panel (110.4 x 34.9cm)




2 Back panel (110.4 x 34.9cm)




3 Top panel (120.1 x 40.1cm)




4 Bottom panel (110.4 x 34.8cm)




5 Left side panel (29.5 x 34.8cm)




6 Right side panel (29.5 x 34.8cm)




7 Front left leg
(37.7 x 5.1cm)



8 Front right leg
(37.7 x 5.1cm)



9 Back left leg
(37.7 x 5.1cm)



10 Back right leg
(37.7 x 5.1cm)




Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  65mm Screw x 8	B  12mm Screw x 18	C  14mm Screw x 10
D  39mm Locking pin x 14	E  15mm Locking nut x 14	F  30mm Dowel x 12
G  Screw cover x 8	H  Foot x 1	I  Hinge x 3
J  Left spring hinge x 1	K  Right spring hinge x 1	

Tools required



Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Fitting the left side and right side panels

a: Screw Locking pins **D** into the Front left leg **7**, Back left leg **9**, Back right leg **10** and Front right leg **8**.


Note: Insert Locking pins as far as shown.
Do not over tighten.

a:




b: Insert Dowels **F** into the Left side panel **5** and Right side panel **6**.

b:




c: Carefully locate the Front left leg **7**, Back left leg **9**, Back right leg **10** and Front right leg **8** onto the Left side panel **5** and Right side panel **6**.

c:



Insert 8 Locking nuts **E** into the Left side panel **5** and Right side panel **6**.

Use a screwdriver to turn Locking nuts **E** clockwise to lock.




Assembly Instructions

Step 2

Attaching front, bottom and back panels


a: Insert Dowels **F** into the Bottom panel **4**.

Use Screws **C** to fix Foot **H** onto the Bottom panel **4**.



b: Screw Locking pins **D** into the Back panel **2** and Front panel **1**.


Note: Insert Locking pins as far as shown. **Do not over tighten.**



c: Carefully locate the Bottom panel **4** onto the Back panel **2**.

Insert 3 Locking nuts **E** into the Bottom panel **4**.

Use a screwdriver to turn Locking nuts **E** clockwise to lock.



Continued on next page.

Assembly Instructions

Step 2 - continued





With help, ask someone to hold the Front panel **1**.

d: Carefully locate the Front panel **1** onto the Bottom panel **4**.

Insert 3 Locking nuts **E** into the Bottom panel **4**.

Use a screwdriver to turn Locking nuts **C** clockwise to lock.

d:




Step 3

Attaching left side and right side panels

Use 8 Screws **A** to fix Left side panel **5** and Right side panel **6** onto the unit.

Use Screws covers **G** to cover the screw heads.




Assembly Instructions

Step 4

Attaching top panel

a: Use Screws **B** to fix the Hinges **I** onto the Door panel **3**.


a:



With help, ask someone to hold the Door panel **3**.

b: Use Screws **B** to fix the Hinges **I** onto the Back panel **2**.

b:




Continued on next page.

Assembly Instructions

Step 4 - continued


c: Use Screws **C** to fix the Left spring hinge **J** and Right spring hinge **K** onto the Left panel **5** and Right panel **6**.

c:



d: Use Screws **C** to fix the Left spring hinge **J** and Right spring hinge **K** onto the Door panel **3**.

d:




Assembly Instructions

Step 5

Finishing the unit

Note: It would be useful to ask someone to help you at this stage.

With help, place the unit in the intended position.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800