


# betsy 3' bed

Assembly Instructions – Please keep for future reference

503/1036



## Dimensions

Length - 201cm

Width - 100cm

Height - 120cm

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6400 800



# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Dispose of all packaging carefully and responsibly.
- Place the product on flat and steady surface during use.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Keep these instructions for further use.
- To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.


## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


# Components - Parts

If you have damaged or missing components,  
call the Customer Helpline: 0345 6400 800


Please check you have all the parts listed below




**1** Headboard panel (100 x 80cm)



**2** Headboard post x 2  
(45 x Ø3.8cm)



**3** Footboard (100 x 80cm)



**4** Side rail x 2 (192 x 5.1cm)











**5** Bentwood slat x 16

# Components - Fittings


If you have damaged or missing components, call the Customer Helpline: 0345 6400 800

Please check you have all the fittings listed below

*Note:* The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


<b>A</b>  13mm Allen screw x 4	<b>B</b>  Plain washer x 12	<b>C</b>  25mm Allen screw x 4
<b>D</b>  32mm Allen screw x 4	<b>E</b>  Rubber washer x 8	<b>F</b>  Nut x 4
<b>G</b>  Allen key x 2	<b>H</b>  Plastic cap x 32	

## Tools required



Ruler/tape  
measure

## Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


## Step 1

### Assembling posts

Place headboard panel **1** face down onto a clean flat surface.

*Note:* Fixing holes for posts should be facing up.

Secure headboard posts **2** to headboard panel **1** using fixings **A** and **B**.




## Step 2

### Assembling side rails

**a:** With help, assemble side rails **4** to the headboard using fixings **B**, **D**, **E** and **F**.

**b:** Assemble footboard **3** to the side rails using fixings **B**, **C** and **E**.




# Assembly Instructions

## Step 3

### Attaching slats

Assemble plastic caps **H** onto each end of bentwood slats **5**.

Fit bentwood slats **5** in between side rails **4** by locating plastic caps **H** into the holes.



Assembly is complete.

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6400 800  
Home Retail Group, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, MK9 2NW