


# betsy 4'6 bed

Assembly Instructions – Please keep for future reference

503/5355



## Dimensions (4'6)

Length - 201cm  
Width - 145cm  
Height - 120cm

## Dimensions (5')

Length - 211cm  
Width - 160cm  
Height - 120cm

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6400 800



# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Dispose of all packaging carefully and responsibly.
- Place the product on flat and steady surface during use.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Keep these instructions for further use.
- To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.


## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


# Components - Parts

If you have damaged or missing components,  
call the Customer Helpline: 0345 6400 800


Please check you have all the parts listed below




**1** Headboard panel (145 x 80cm) (160 x 80cm)




**2** Headboard post x 2  
(45 x Ø3.8cm)




**7** Support leg x 2  
(24 x Ø2.5cm)




**8** Bentwood slat x 32




**3** Footboard panel (145 x 80cm) (160 x 80cm)



**4** Side rail x 2 (193.7 x 10.8cm) (203.7 x 10.8cm)



**5** End support x 2 (136.5 x 4cm) (151.7 x 4cm)













**6** Central support (183 x 9cm) (187.8 x 9cm)

# Components - Fittings


If you have damaged or missing components, call the Customer Helpline: 0345 6400 800

Please check you have all the fittings listed below

*Note:* The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  <b>15mm Allen screw x 12</b>	<b>B</b>  <b>Plain washer x 22</b>	<b>C</b>  <b>25mm Allen screw x 4</b>
<b>D</b>  <b>32mm Allen screw x 4</b>	<b>E</b>  <b>Rubber washer x 8</b>	<b>F</b>  <b>Nut x 4</b>
<b>G</b>  <b>45mm Allen screw x 2</b>	<b>H</b>  <b>Allen key x 2</b>	<b>J</b>  <b>Central plastic cap x 16</b>
<b>K</b>  <b>Plastic cap x 32</b>		

## Tools required



Ruler/tape  
measure

## Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


## Step 1

### Assembling posts

Place headboard panel **1** face down onto a clean flat surface.

*Note:* Fixing holes for posts should be facing up.

Secure headboard posts **2** to headboard panel **1** using fixings **A** and **B**.




## Step 2

### Assembling side rails

**a:** With help, assemble side rails **4** to the headboard using fixings **B**, **D**, **E** and **F**.

*Note:* Ensure the metal brackets are at the bottom as shown.

**b:** Assemble footboard **3** to the side rails using fixings **B**, **C** and **E**.



# Assembly Instructions


## Step 3

### Securing end supports

Locate end supports **5** into the metal brackets on the inside of side rails **4**.

**Note:** Ensure the fixing holes are on the inside as shown.

Secure using fixings **A** and **B**.




## Step 4

### Assembling central support

Locate central support **6** in between end supports **5** and secure using fixings **A** and **B**.

Assemble support legs **7** to the underside of central support **6** using fixings **B** and **G**.



# Assembly Instructions


## Step 5

### Attaching slat caps

Assemble plastic caps **K** onto one end of bentwood slats **8**.

**a:** Fit plastic caps **K** into the slotted holes in side rails **4** as shown.

**b:** Fit bentwood slats **8** into both sides of central plastic caps **J** before pushing caps **J** into central support **6**.



**Assembly is complete.**

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6400 800  
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW