# How to fold away


**9 months +**

1.




Leave the unit in the middle of the mat.

2.



Pull the front and back of the mat together and hold in place with the yellow hook and loop fastener.

3.




Attach the sides (as shown) together using the white hook and loop fastener.

4.



Attach the sides (as shown) together using the black hook and loop fastener.

5.



x 10



**WARNINGS**

- Keep away from fire.
- Adult supervision required.
- For indoor use only.
- Charging of the product to be carried out by adults only.
- Do not immerse the product in water.
- Wipe clean with a damp cloth prior to use and storage.
- Adults should regularly inspect the product for damaged or broken parts.
- Retain these instructions for future reference.



Help the environment by disposing of your product responsibly.
The wheelie bin symbol indicates that the product must not be disposed of in the domestic waste, as it contains substances which can be damaging to the environment and health. Please use designated collection points or recycling facilities when disposing of the item.


http://www.recycle-more.co.uk
www.recyclenow.com

Made in China, Produced for Chad Valley Toys, Argos Ltd.
Address: 489 - 499 Avebury Boulevard, Central Milton Keynes, MK9 2NW.
www.argos.co.uk/chadvalley


Cat no 531/5075
INS.321CHV-AO 19/05/16

# How to use

Switch the unit to ON.
(as per visual)






You can place a ball onto the unit and press the big button on the front to float the ball or you can press the big button and place the ball into the air flow.




# Charging


Insert the micro USB cable into the unit and then connect to your own USB plug.





USB Plug not supplied.



Charging.

Charged.

Ensure the unit is in the **ON** position when charging. Charging the unit to full capacity will take approximately 8 hours.

When charging the unit the light will flash. Once fully charged the light will remain constant.
(As a safety measure the unit will not power on when charging).

Remove the micro USB cable before use.