
## Components

# TC NEW PAOLO CHAIR POWERED

A 1 x Seat Unit



B 1 x Back Rest

1 x Left Arm Cushion D 1 x Right Arm Cushion




 $\bigcirc$ 

# Arm Cushion








### Important-Please read these instructions fully before starting assembly

If you need help or have damaged or missing pants,call theCustomer Helpline: 0345 640 0800 0345 601 2895

## Fittings

#### ©1xMains Electricity Supply



- **1**. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- 2. Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.
- **3**. Take all the fittings out of the plastic bag and separate them into their groups.
- **4**. Ensure you have enough space to lay out all the parts before assembly.
- **5**. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

# **Assembly Instructions**

# **Assembly Instructions**

## Stage 1 – Fitting the Unit

- NOTE: It would be useful to ask someone to help you at this stage.
- 1. One armrest is tied the bottom of sofa.and the other is put behind of seat cushion See fig.1.
- 2. Firstly attach the arm cushion. You can find the assembly steps in the last page.
- 3. Attach the Back Rest (B) to the Seat Unit (A). Engage the metal locks and push fit. You should hear them lock into position. See fig. 2.
- 4. Fit the velcro cover which is on the back rests onto the velcro on the seat cushion.

NOTE: Carefully line up the two side metal locks. Ensure they align correctly.





fig. 1



WARNING: If the supply cord is damaged, it must be replaced by the manufacturer. its service agent or similarly qualified persons in order to

5.Remove and unpack the fittings which are stored under the Seat Unit (A). See fig.3.



## CAUTION:


avoid a hazard.

- Beware of entrapment. Keep \_ hands and fingers clear of the tilt mechanism when operating the controls.
- Ensure that children or pets are not playing or lying in the way when the tilt mechanism is operated.
- Prevent children from playing on the furniture or with the controls.



WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WAS TE.PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYALING ADVICE.

NOTE: It would be useful to ask someone to help you at this Stage.



# Assembly Instructions

# **Assembly Instructions**

## Stage 2 - Arm cushion assembly steps

## Stage 3 – Operating the Unit

 Please fix the arm cushion by zipping it onto the outside of the armrest.

See fig.4.



fig. 4

2. Adjust the arm cushion with the right position onto the armrest .

See fig.5.



fig. 5



#### Back and Foot Rest Adjustment

This Chair features a reclining back rest and raised foot rest. You need to be sitting in the chair to activate the features.

- 1. Press the "Adjustment Leverfront button", the chair will recline and the foot rest will automatically lift up. See fig.7.
- Press the "Adjustment Leverback button". The sofa return to the normal position.
  See fig.7.
- 3. Adjust the recliner to your own requirements.
- Finally carefully place the unit in the desired location.
  See fig.8.

## Care and Maintenance

#### Safety

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

#### Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Adjustment Lever

0

fig. 7

fig.8

#### Fitting

From time to time please ensure there are no loose screws on the product. if you need help or have damaged or missing parts,call the Customer Helpline: 0345 640 0800/0345 601 2895

489-499 Avebury Boulevard Milton Keynes MK9 2NW, Argos Limited

 Press the seat cushion next to the inside of armrest. then stick the velcro into the inside of armrest.
See fig. 6.