
EYDON GLASS TABLE

Assembly Instructions



Before you start, here is some helpful advice

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.

2.If you follow the instructions carefully the end result should be worth the effort.

3.Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.

4.Assemble this product on a carpet.

5.To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.

6.We recommend a periodic check on all fixing points to make sure they remain fully tightened.





7.Keep glue and fittings out of children's reach.

Note: It will require two people to assemble this item





After-sales telephone number for spare parts : 0870 600 8990.

Component parts and fittings contained in the box


PARTS

① x2PCS	② x2PCS
	
③ x1PC	④ x1PC
	

FITTINGS

	 M8x12mm
Ⓐ x4PCS	Ⓑ x4PCS
 Nylon Coated M6x12mm	
Ⓒ x8PCS	Ⓓ x4PCS
 spring washers	
Ⓔ x4PCS	Ⓕ x1PC
	
Ⓖ x1PC	

ASSEMBLY




1) Place table top ④ upside down onto a clean flat surface.
2) Assemble legs ① and ② to table top using fixings B and D E. Rubber washers D go in between the frame and the top.

Note: Legs ① must be located diagonally opposite each other and legs ② must be located diagonally opposite each other.

Important: Leave screws loose at this stage!


3) Screw self levelling feet A into the ends of the legs.

STEP 1



1) Locate central tube ③ in position as shown and secure using fixings C.
2) Fully tighten all fixing screws.

STEP 2



Customer information

Keep these instructions for further use

PRODUCT INFORMATION

- This product complies with BS7376:2004
- Imported by:

  Argos ltd
  Avebury boulevard
  Saxon gate west
  Milton keynes
  MK9 2nw

- Product stock ref:600/5487D
- P/O NO : 519927

If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.

WARNINGS

a) Do not place very hot or very cold items on the glass surface(s)unless adequately thick table mats are used to prevent such items from coming into contact with the glass.

b) Do not sit or stand upon the glass surface(s).

c) Do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items.


d) When cleaning glass panels or mirrors use damp cloth or leather with washing up liquid or soft soap if necessary. Do not use washing powders or any other substance containing abrasives since these substances scratch glass.

Eydon Bistro Table

Assembly Instructions - Please keep for future reference

600/0516

600/1711



Dimensions

Length - 90cm
Width - 90cm
Height - 76cm

Important - Please read these instructions fully before starting assembly

If you need or have damaged or missing parts, call the **Customer Helpline:08456 400800**

Issue 1 - 19/11/09

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Assembly to be carried out by a competent adult only.
- Parts of the assembly will be easier with 2 people.
- To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.
- Do not use this item if any components are missing or damaged.
- During assembly children should be kept away from the product due to possible risk of injury.
- Remove all fittings from the plastic bags and separate them into their groups.
- Dispose of all packaging carefully and responsibly.
- Do not stand or put excessive weight on the product, this could cause damage.
- Check you have all the components and tools listed on page 2 and 3.
- Retain these instructions for future reference.

Glass safety

- This product complies with BS7376:2004
- Imported by:
Home Retail Group
489-499 Avebury Boulevard
Saxon Gate West
Central Milton Keynes
MK9 2NW
- Product stock ref: 600/0516(D) (Clear Glass)
600/1711(D) (Black Glass)
- P/O No:
- If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.

Warnings

a) Do not place very hot or very cold items on the glass surface(s) unless adequately thick table mats are used to prevent such items from coming into contact with the glass.

b) Do not sit or stand upon the glass surface(s).

c) Do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items.


d) When cleaning glass panels or mirrors use damp cloth or leather with washing up liquid or soft soap if necessary. Do not use washing powders or any other substance containing abrasives since these substances scratch glass.

Care and maintenance


- This product should not be discarded with household waste. Take to your local authority waste disposal only.
- Regularly check all fastenings to ensure that they properly tightened.

Components - Parts


Please check you have all the parts listed below




1 Leg x 2 (73 x 39 cm)



2 Leg x 2 (73 x 39 cm)



3 Central tube x 1 (11 x 3.8 cm)



4 Glass top (90 x 0.6 cm thickness)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Self levelling feet x 4	**B**  12mm M8 Allen screw x 4	**C**  12mm M6 Allen screw x 8 (nylon coated)
D  Rubber washer x 4	**E**  Spring washer x 4	**F**  Large allen key
G  Small allen key x 1		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Attaching legs


Warning:
With help, carefully place table top 4 upside down onto a clean flat surface.

a: Assemble legs 1 and 2 to table top 4 using fixings Ⓑ , Ⓓ and Ⓔ . Rubber washers Ⓓ go in between the frame and the top.

Note: Legs 1 must be located diagonally opposite each other and legs 2 must be located diagonally opposite each other.

Note: Do not fully tighten screws Ⓑ .

b: Screw self levelling feet Ⓐ into the ends of the legs 1 and 2 .



Step 2

Attaching central tube


Locate central tube 3 in between the leg brackets as shown and secure using fixings Ⓒ .

Fully tighten all fixing screws.

With help, carefully stand the table upright.

Warning:
The table is heavy. Lift with care.


Assembly is complete.



If you need help for have damaged or missing parts, call the **Customer helpline:08456 400800**
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW

UPHOLSTERED BISTRO CHAIR

Assembly Instructions



Before you start, here is some helpful advice

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.

2.If you follow the instructions carefully the end result should be worth the effort.

3.Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.

4.Assemble this product on a carpet.

5.To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.

6.We recommend a periodic check on all fixing points to make sure they remain fully tightened.




7.Keep glue and fittings out of children's reach.

Note: It will require two people to assemble this item

After-sales telephone number for spare parts : 0870 600 8990.

Component parts and fittings contained in the box

PARTS

①x4PCS	②x4PCS
	
③x4PCS	④x8PCS
	

FITTINGS



Ⓐ x 16pcs




Ⓑ x 16pcs



Nylon Coated

Ⓒ x 16pcs




Ⓓ x 16pcs



Ⓔ x 16pcs



Ⓕ x 16pcs



Ⓖ x 1pc



Ⓗ x 1pc




Ⓘ x 16pcs

ASSEMBLY



1) FIT END CAPS Ⓐ AND Ⓑ INTO CHAIR BACK ① AND FRONT LEGS ④


STEP 1



1) ASSEMBLE SEAT RING ③ ONTO CHAIR BACK. ① USING FIXINGS Ⓓ, Ⓔ AND Ⓕ

NOTE: THE LABEL ‘F’ ON SEAT RING ③ IDENTIFIES THE CORRECT BRACKETS FOR FRONT LEGS ④.

STEP 2




ASSEMBLY



1) FIT FRONT LEGS ④ TO THE BRACKETS IDENTIFIED WITH 'F' USE FIXINGS ⓒ TO SECURE


STEP 3



"Important-Please take care not to over tighten the fixing screws".

1) PLACE SEAT PAD ② UPSIDE DOWN ON A CLEAN, FLAT SURFACE. SECURE USING FIXINGS ①.

STEP 4



SHOWN UPSIDE DOWN

CLEANING GUIDANCE


Minor stains and spillages should be removed immediately from cushion fabric,by wiping over lightly with a damp cloth and mild soapy water.Do not soak the fabric or shrinkage may occur!Light marking can also be removed using this method.
To remove more stubborn stains or marking,a good quality proprietary domestic fabric cleaner can be used,although it should first be tested on and inconspicuous area of the fabric.

Eydon Bistro Chair

Assembly Instructions - Please keep for future reference

600/0516

600/1711



Dimensions

Width - 48.5cm
Depth - 45.5cm
Height - 85cm

Important - Please read these instructions fully before starting assembly

If you need or have damaged or missing parts, call the **Customer Helpline:08456 400800**

Issue 1 - 19/11/09

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Assembly to be carried out by a competent adult only.
- Parts of the assembly will be easier with 2 people.
- To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.
- Do not use this item if any components are missing or damaged.
- During assembly children should be kept away from the product due to possible risk of injury.
- Remove all fittings from the plastic bags and separate them into their groups.
- Dispose of all packaging carefully and responsibly.
- Do not stand or put excessive weight on the product, this could cause damage.
- Check you have all the components and tools listed on page 2 and 3.
- Retain these instructions for future reference.

Cleaning Guidance


- Minor stains and spillages should be removed immediately from cushion fabric, by wiping over lightly with a damp cloth and mild soapy water.
- Light marking can also be removed using this method.
- To remove more stubborn stains or marking, a good quality proprietary domestic fabric cleaner can be used, although it should first be tested on and inconspicuous area of the fabric.

Care and maintenance


- This product should not be discarded with household waste. Take to your local authority waste disposal only.
- Regularly check all fastenings to ensure that they properly tightened.

Components - Parts


Please check you have all the panels listed below




1 Back rest x 4 (84 x 43 cm)



4 Front leg x 8 (41 x 1.9 cm)



2 Seat pad x 4 (40 x 5.5 cm)







3 Seat frame x 4 (41.5 x 8 cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Domed end cap x 16	**B**  Flat end cap x 16	**C**  16mm Allen screw (nylon coated) x 16
D  30mm Allen screw x 16	**E**  Nut x 16	**F**  Metal washer x 16
G  Allen key x 1	**H**  Spanner x 1	**J**  16mm Allen screw x 16
K  Spring washer x 16		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Fitting plastic caps

a: Lay back rest [1] flat onto the floor.

Insert chrome effect domed end caps Ⓐ into the top of back rest [1].


Insert flat end caps Ⓑ into the bottom of back rest [1].

Repeat for all back rests.

b: Insert chrome effect domed end caps Ⓐ into the top of front legs [4].

Insert flat end caps Ⓑ into the bottom of front legs [4].

Repeat for all other front legs [4].




Step 2

Attaching front legs

Fit front legs [4] to seat ring [3] using fixings Ⓒ.

Note: The legs must be fitted alongside the brackets identified 'F' (Front).

Important: Please take care not to over tighten the fixing screws.




Assembly Instructions

Step 3

Attaching seat frame

Assemble seat frame [3] to back rest [1] using fixings Ⓓ , Ⓔ , Ⓕ and Ⓚ .




Step 4

Attaching seat pad

Place seat pad [2] upside down onto a clean flat surface. (Suggest edge of table as shown)

Align the chair frame on the seat pad and secure using fixings Ⓙ .



Assembly is complete.

If you need help for have damaged or missing parts, call the **Customer helpline:08456 400800**
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW