
Ottawa Bar Stool

Assembly Instructions - Please keep for future reference

600/0444
600/5645
600/0468
642991
627379



Dimensions

Width - 47cm
Depth - 45cm
Height - 78-100 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Issue 3 - 07/07/12

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• We suggest you spend a short time reading through this leaflet and follow the simple step by step assembly instructions.

• Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.

• Assemble this product on a flat surface.

• Assemble all parts loosely before tightening any bolts.

• Discard all extra fittings and keep fittings out of reach of children.

• Unit weight: 6.3kgs.

• Maximum safe weight of user: 100kgs.

• Retain Assembly Instructions for future reference.



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging care fully and responsibly.

Warnings

• Do not stand on the stool.

• Do not use the stool as a step ladder.

• Do not sit with sharp objects in back pockets as this may damage the seat surface.

• Do not knock the surface of the seat against sharp solid surfaces.

Care and maintenance

• Please clean the seat surface using either damp (not wet) cloth and a mild domestic soap solution or by using an appropriate polish.


• Do not use any abrasive materials when cleaning.

• From time to time check that there are no loose bolts on this unit.


Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the parts listed below




1 Seat
(41 x 47 x 23.5cm)




2 Upper leg
(Ø5.8 x 39.5 x 16cm)




3 Gaslift
(Ø5 x 50-72cm)



4 Footrest
(29 x 21 x 3.3cm)



5 Decor ring
(Ø6.3 x 7.5 x 2.2cm)





6 Base
(Ø38.5 x 8.5cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  M6 x 15mm Bolt x 4	**B**  Washer x 4	**C**  Stud bolt x 1
D  Allen key x 1		

Tools required




Crosshead
Screwdriver

Assembly Instructions

Step 1

Attaching upper leg


Place the seat 1 upside down on a flat protected surface. Position the upper leg 2 and make sure that the lever is at your left hand side as shown in the diagram. Secure using washer B and bolt A. Tighten bolts using a screwdriver.



Step 2

Attaching footrest

Connect the footrest 4 into the upper leg 2 by turning it clockwise.




Step 3

Attaching gaslift

Place the base 6 on a flat protected surface. Position the decor ring 5 on the base and insert the gaslift 3 into the decor ring and hole of the base.

Important:
Remove plastic tip cover on gaslift before assembling.




Assembly Instructions

Step 4

Attaching the seat


Position the seat as shown and insert the gaslift 3 into the upper leg 2. Secure by pressing down the seat firmly.




Step 5

Securing footrest

Adjust the footrest 4 and make sure to centre align it with the seat 1. Then secure using stud bolt C as shown and tighten using allen key D.





Gaslift operation

To adjust the seat higher, lift up the lever under the seat and release at desired height.

To lower the seat, lift up the lever while seated on the stool.


Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Ottawa Bar Stool

Assembly Instructions - Please keep for future reference

600/0444
600/5645
600/0468
397/6313
194803
194806



Dimensions

Width - 47cm
Depth - 45cm
Height - 78-100 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800 Homebase = 0345 077 8888

Issue 4 - 31/03/15

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Parts of the assembly will be easier with 2 people.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Do not stand on the stool.

• Do not use this stool as a step ladder.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

• Unit weight: 6.3 kgs.

• Maximum safe weight of user: 110kgs.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

• Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Parts

If you have damaged or missing components, call the
Customer Helpline: Argos = 0345 640 0800
Homebase = 0345 077 8888

Please check you have all the parts listed below




1 Seat
(41 x 47 x 23.5cm)




2 Upper leg
(Ø5.8 x 39.5 x 16cm)



3 Gaslift
(Ø5 x 50-72cm)



4 Decor ring
(Ø6.3 x 7.5 x 2.2cm)





5 Base
(Ø38.5 x 8.5cm)

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A 	**B** 	**C** 
M6 x 15mm Bolt x 4	Washer x 4	Allen key x 1


Assembly Instructions

Step 1

Attaching upper leg

Place the seat [1] upside down on a flat protected surface. Position the upper leg [2] and make sure that the lever is at your left hand side as shown in the diagram. Secure using washer Ⓑ and bolt Ⓐ. Tighten bolts using allen key Ⓒ.






Step 2

Attaching gaslift

Place the base [5] on a flat protected surface. Position the decor ring [4] on the base and insert the gaslift [3] into the decor ring and hole of the base.

Important:
Remove plastic tip cover on gaslift before assembling.




Assembly Instructions

Step 3

Attaching the seat


Position the seat as shown and insert the gaslift [3] into the upper leg [2]. Secure by pressing down the seat firmly.



Gaslift operation

To adjust the seat higher, lift up the lever under the seat and release at desired height.

To lower the seat, lift up the lever while seated on the stool.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800 Homebase = 0345 077 8888