



Assembly Instructions QF 5207-01

Article No.: 012168-xx-01-2436

Date: Prepared by: Checked by:

9-Apr-10 CS

Article no.: Description: Size: Family Code:

012168-xx-01-2436 Bentwood dining chair W460XD560XH870mm

Assembly instruction

Edition No.: 1 (Date: 9/4/2010)


REVISION HISTORY

Revised	Date	Change Details	Prepared
Edition	DD/MM/YY		Ву




Article No.: 012168-xx-01-2436

Assembly instruction





Article No.: 012168-xx-01-2436



Dining Chair

Assembly Instructions - Please keep for future reference


600/6039

600/6053

600/6022

600/6046

600/6077



Dimensions

Width - 46cm

Depth - 54cm

Height - 87cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the

Customer Helpline: 0845 640 0800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product during assembly, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Parts


Please check you have all the parts listed below







2 Top leg (64.5 x 43.3 cm)



3 Bottom leg (64.5 x 43.3 cm)

Components - Fittings

If you have damaged or missing components, call the Customer Helpline: 0845 640 0800

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

		6
Bolt x 4 (M6 x 32mm)	Bolt x 1 (M6 x 15mm)	Spring washer x 5 (M6)
	()	6 =
White connector x 4 (5/8")	Plastic feet x 4	Rubber cap x 4
G Allen key x 1		

Tools required

Ruler/tape measure


Ruler - Use this ruler to help correctly identify the screws

Assembly Instructions

Step 1

Attaching connectors and feet to the legs.

Slide the white connectors
on legs 2 and 3.
Insert plastic feet fully into the ends of legs 2 and 3.




Step 2

Attaching leg 2 to chair seat.

Place the seat 1 on a covered table top.
With the arrow marks on the legs pointing to seat front, move the connectors so that they are aligned to the holes of the leg and the screw threads on the seat. Assemble the legs to the chair seat with bolt using allen key

Continued on next page.




Assembly Instructions

Step3 - continued

Attaching leg 3 to chair seat.

With the arrow marks on the legs pointing to seat front, move the connectors so that they are aligned to the holes of the leg and the holes on the seat.

Assemble the legs to the chair seat with bolt ausing allen key .



Step4

Final Assembly


Fasten bolt B with washer

where legs 2 and 3 overlap.

Cover the white connector

with Rubber cap .

Turn the chair over carefully.



If you need help or have damaged or missing parts, call the Customer Helpline: $0845\ 640\ 0800$ Argos Ltd MK9 2NW