
OXFORD DINING FURNITURE

Extendable Dining Table

Easy Assembly Instructions




Before you start, here is some helpful advice

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
3. Assemble this product on a carpet.
4. All you will need to assemble this unit is a screwdriver and light hammer.
5. Keep glue and fittings out of childrens' reach.

In the unlikely event that this product has missing or damaged parts, please call 0845 640 0800 to obtain spares.

Component parts and fittings contained in the box


Extendable Dining Table




Total: 7 Parts

Fittings


A — M8x80mm Bolt x 8



B — ∅12x60mm Nut x 4




C — M8x13mm Nut x 8



M16/8.5x1.2mm Washer x 8

D




M13/8.5x2.5mm Gasket x 8

E




W13.5xT2mm Spanner x 1

F




43x35x34mm x4

G



ASSEMBLY - STAGE ONE




Leg Assembly

1. Insert Ⓑ into ②.

2. Screw in bolts Ⓐ into Ⓑ.


3. Repeat for all four legs.




4. Set the legs onto the base of table.

5. Screw in the nuts Ⓒ with the Ⓔ and Ⓓ by Ⓕ.

6. Tighten the nuts.




ASSEMBLY - STAGE TWO




Leaf Assembly

7. Insert ③ into the holes of short rail (x2). Make sure the rails of ③ are held securely by the wedge under the table.




ASSEMBLY - STAGE THREE



How to shorten the table

8. To shorten the table, remove the leaves ③ from the sides. Turn them over, and insert them under the top ①, one on each side. Turn the wood block between the leaves under the table to hold them in place.


9. Fill in the holes of short rail with four wood blocks Ⓖ.



Oxford - Extendable Dining Table

Assembly Instructions - Please keep for future reference

603/0438



Dimensions

Length - 210cm

Width - 90cm

Height - 75cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 1 - 9/12/09

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance


• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below



1 Top (150 x 90cm)



2 Leg x 4 (73 x 6.5cm)



3 Extension panel x 2 (90 x 61.8cm)

Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  80mm Bolt x 8	B  60mm Assembly bolt x 4	C  13mm Nut x 8
D  Washer x 8	E  Spring washer x 8	F  Spanner x 1
G  Cover block x 4		

Tools required



Ruler/tape measure

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Fitting bolts

Insert assembly bolt B into leg 2, screw bolts A into assembly bolt B.




Repeat with remaining legs 2.

Step 2

Attaching legs

Attach four legs 2 to top 1 using washer D, nut C, and spring washer E. Tighten the bolts with spanner F.




Assembly Instructions

Step 3

Attaching extension panels

a: Insert extension panel 3 into the holes of short rail(x2).

Make sure the rails of extension panels 3 are held securely by the wedge under the table.




Attaching extension panels

b: To shorten the table, remove extension panels 3 from the sides. Turn them over, and insert them under the top 1, one on each side.

Turn the wood block between the extension panels under the table to hold them in place.

Fill in the holes of short rail with cover blocks(x4) G.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Argos Ltd MK9 2NW