
Warwick Chair

Assembly Instructions - Please keep for future reference

6038447

6037819



Dimensions

Width - 46.5cm Depth - 54cm Height - 99cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



!\ Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommended the use of power drill/drivers for inserting screws,

as this could damage the unit.
Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.
- The maximum safe weight of user: 110 Kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This produt should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


If you nave damaged or missing components, call the Customer Helpline: 08456 400800

Please check you have all the panels listed below

NOTE: Components, listed below are required for one chair only.



1 Backrest x 1 (29.6 x 99cm)




2 Front Leg x 1 (43 x 43cm)



3 Right Side Stretcher x 1 (36 x 5.8cm)




4 Left Side Stretcher x 1 (36 x 5.8cm)



5 Right Side Rail x 1 (39.8 x 2.2cm)



6 Left Side Rail x 1 (39.8 x 2.2cm)



7 Seat Cushion x 1 (46.5 x 40cm)





Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly for one chair. In some cases more fittings may be supplied than are required.







Assembly Instructions

Step 1

Fitting the Side Stretcher

Note: It would be useful to ask someone to help you at this stage.

a: Insert Screw 🛕 ,Spring washer B, Flat washer C with Allen key **(D)** to fix side stretcher 3 4 onto backrest.

Note: Do not fully tighten all the screws

Fitting the Side Rail

Note: It would be useful to ask someone to help you at this stage.

b: Insert Screw (a) to fix side rail 5 6 onto back back rest 1

Note: Do not fully tighten

all the screws

Step 2


Fitting the Front Leg


Note: It would be useful to ask someone to help you at this stage.

c: Insert Screw (A), Spring washer B, Flat washer C with Allen key (1) to fix front leg 2 onto side stretcher 3 4

d: Insert Screw (1) to fix side rail 5 6 onto front leg 2

Note: Do not fully tighten all the screws





Assembly Instructions


Step 3

Fitting the Cushion

Note: It would be useful to ask someone to help you at this stage.

e: Use Screw to fix cushion seat onto the unit.

Note: Fully tighten all the screws now.



Assembly Instructions

Step 4

Finishing the unit

Note: It would be useful to ask someone to help you at this stage.

With help, place the unit in the intended position.

Note: Before use always make sure the unit is secure.


Note: The maximum safe weight of user: 110kg.



Warning:

- •Do not stand on this chair. Do not use this chair as a step ladder.
- •Use this product only for seating one person at a time.
- •Do not use this chair unless all bolts, screws and knobs are firmly secured.
- •At least every 4 months, check all bolts, screws and knobs, to be sure they are tight.
- If parts are missing, broken or damaged or worn, stop use of this product until repairs are made & using factory authorized parts.
- Failure to follow these warnings could result in serious injury.

Assembly is complete.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800