MADRID SQUARE DINING TABLE

Assembly Instructions - Please keep for future reference | 6110657



Dimensions
Width - 96.5cm Depth - 96.5cm Height - 71cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456400800
For further assistance please visit http://www.argos-support.co.uk/

⚠ Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break in to a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of Injure from glass breaking into large shards.

• If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.

• Check you have all the components and tools listed on page 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels during assembly, this could cause damage.

• Assembly on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

• Do not sit or stand on this table.

• Do not place very hot or very cold items on the glass.

• Warning: The unit weighs approximately 16.3 kgs. Please lift with care.

Care and maintenance

• Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame parts.

• Wash glass with mild soap and water, rinse thoroughly, and dry completely.

• Do not use washing powders or any abrasive substances which may scratch the surface.

• Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your table.

• When moving the table, lift. Do not drag this table.

• We recommend the use of furniture covers when not in use.





• In order to prolong the life and beauty of your table, we recommend that it be stored in a dry and protected area when not in use.

• Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.

Components - Fittings


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly.

A  ST4.2x12 Screw x 4	B  M6 x 55mm Bolt x 8	C  D13 Washer x 8
D  D10 Washer x 8	E  M6xP1.0 Plastic Nut x 8	

Components - Parts


Please check you have all the parts listed below




1 Table Top x 1



2 Leg x 4



3 Center Connector x1



4 Center Connector With Ring x1


Tools required



4mm Hex Key





10 & 13mm Nut Wrench



Screwdriver (Not provided)

Ruler - Use this ruler to help correctly identify the screws






E-3

Assembly Instructions


Step 1

Place the table top [1] onto a non-abrasive surface, such as a carpet, with its underside facing upwards. Insert the legs [2] into the plastic holders attached on the underside of the table top [1] rim. Fix them together by using screws (A).



Step 2


Fix the center connector [3] to the middle of the legs [2] by using bolts (B), washers ((C) and (D)) and plastic nuts (E). Keep the bolts loose.



Assembly Instructions

Step 3

Fix the center connector with ring [4] to the middle of the legs [2] by using bolts (B), washers ((C) and (D)) and plastic nuts (E). Make sure that all of the bolts have been tightened completely.




Step 4

Turn the table to its upright position.

Note:
To use an umbrella with this table, remove the center plug and put the umbrella pole through the table top and center connector ring.

A weighted umbrella base shouid be used when using an umbrella with this table.

Assembly is completed.



⚠ Warning: Don't detach the plastic support from the table frame! It is for glass support!

If you need help or have damaged or missing parts, call the Customer Helpline: 03456400800
For further assistance please visit http://www.argos-support.co.uk/
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW