
RIO 4 Seater Sofa Set - Double Sofa

Assembly Instructions - Please keep for future reference

608/9805



Important:
Do not fully tighten all screws until assembly is complete.

Dimensions

Width - 133cm
Depth - 81.5cm
Height - 79cm

Important Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800
For further assistance please visit http://www.argos.support.co.uk/
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Issue 2: 05/ 09/15

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product during assembly, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the chair or your floor
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers for inserting screws , as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.
- Maximum safe seated weight: 220kgs.


Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- Make sure each studs matches the corresponding figure to ensure correct assembly.
- From time to time check that there are no loose nuts on this chair.
- Assemble all parts and nuts loosely during assembly,only once the product is complete should you fully tighten the nuts.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components-Parts

If you have damaged or missing components, call the Customer Helpline: 0345 640 0800
For further assistance please visit http://www.argos.support.co.uk/

Please check you have all the parts listed below




1 Seat x 1




2 Front Leg x 2



3 Rear Leg x 2



4 Seat Cushionx 1




4 Back Cushionx 2


Components-Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly.In some cases more fittings may be supplied than are required.


Ⓐ 	Ⓑ 
Screw x 12 M6x20	Washer x 12 M6

Tools required



1 x Allen key

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step1

Fit legs to the seat

Use screw Ⓐ, washer Ⓑ to fix the legs 2 3 to the seat 1.




Important:
Do not fully tighten screws at this stage.

Step 2

Tighten all the screws

Tighten all the screws then turn the chair to its upright position and put seat cushion 4 and back cushion 5 on the chair.



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800
For further assistance please visit http://www.argos.support.co.uk/
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW