


Romantic Coffee Table

Assembly Instructions - Please keep for future reference

626/9728



Dimensions

Width - 80cm

Depth - 45cm

Height - 45cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the
Customer Helpline: Argos = 0345 6400800


Please check you have all the panels listed below



1 Table Top (80 x 45cm)



3 Frame shelf (75 x 40cm)



2 Legs x 4 (42.5 x 4cm)




Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  50mm Bolts x 8	B  16mm Flat washer x 8	C  10mm Spring washer x 8
D  Allen key x 1	E  20mm Pads x 4	


Tools required



Phillips screwdriver
(medium & large)




Ruler/tape
measure



Flatblade screwdriver
(medium)

Ruler - Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

Assembly Instructions

Step 1

Assembly legs


Attach Legs **2** to Table Top **1** Using bolts **A**, spring washer **B** and flat washer **C**. Tighten with supplied allen key **D**. Do not over tighten.



Step 2

Assembly frame shelf

Position frame shelf **3** into the legs **2** Using bolts **A**, spring washer **B** and flat washer **C**. Tighten with supplied allen key **D**. Do not over tighten.




Assembly Instructions

Step 3

Assembly legs

Position leg **2**
to table top & frame shelf
Using bolts **A**
spring washer **B** and
flat washer **C**. Tighten
with supplied allen key **D**
Do not over tighten.



Step 4

Attach the pad

Remove cover paper on the
pad **E**. Attach the pad
into under the legs.
With help stand the coffee
table upright.

