
Shelving Assembly Instructions

Assembly & User Instructions - Please keep for future reference **700-3024**



IMPORTANT SAFETY WARNINGS

- Please read the instructions before assembly.
- 2 people are recommended for assembly.
- BE CAREFUL of sharp edges when assembling.
- DO NOT stand on this product or use as a ladder.
- DO NOT alter this product in any manner that is not intended. This may cause product damage or personal injury.
- Position the product on a level surface.
- The maximum loaded weight for each shelf is no more than 175kg. Evenly distributed.
- When loading shelves, place heavier items on the lower shelves, distributing the load evenly.
- Fasten the unit to the wall whenever possible with proper fasteners (not furnished).
- Check the suitability of the wall type and to check that the fastening devices will be able to withstand the forces generated. Consult a competent person if in doubt.

Important

MAX. Load per Shelf: 175kg

MAX. Load for whole unit: 875kg


Tools Required:
A Mallet (not included)



Tool for assembly

Shelf Dimensions: 183H x 91.5W x 45.8D cm

Components



PARTS LIST

A. Posts (8)

B. Shelves (5)


C. Long Apron (10)

D. Short Apron (10)

Important:
Be sure to line up and match hole pattern on all posts prior to assembly.


1

- Place post upright, using cardboard or other safeguard beneath post to protect floor.
- Insert tabs on long shelf support apron into slots on post.
- Press on tabs with fingers to guide into slots.
- Push down or gently tap apron corner with rubber mallet to extend tabs through slots.
- It is recommended that the bottom shelf aprons be placed in the second and third slots from the bottom.
- To ensure stability of the vertical unit, do not place bottom shelf aprons any higher than the sixth slot.




2

Next, insert tabs of a short apron into the front post, creating a “tripod.” Then alternate insertion of support aprons with posts.



3

Place shelves starting at the bottom as you build each layer. Gently tap the top of the shelf around each corner with a rubber mallet until tabs are flush with slots.




This unit can be assembled upright (vertically) or side-by-side (horizontally).

For vertical assembly

- The posts are attached using a shelf support apron at the mid-level of the unit.
- To attach using the aprons, begin with a short apron.
- First insert top apron tab into the bottom slot of the upper post section, as shown in illustration A, and then insert the lower apron in the top slot of the lower post section as shown in illustration B.
- Repeat this process at the other end of the short apron.
- Insert a long apron by again inserting the lower tab into the top slot of the lower post section and top apron tab into the bottom side of the upper post section (illustrations C, D).
- If needed, the unattached end of the long apron can be rested on the lower post section, joining of lower and upper post sections using the aprons until all are installed.


4



IMPORTANT NOTICE

- When assembling your unit it is recommended that you place the top shelf aprons in the first and second slots from the top.
- When moving assembled unit, always handle by the lower half. Recheck all apron tabs/slots being sure they are securely seated.
- To ensure stability of the unit, do not place the top shelf aprons any lower than the sixth slot. This applies to both vertical and horizontal assembly.

For Horizontal Assembly



Care and Maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.
- From time to time check that there are no loose fitting or parst on this unit.
- Do not overload the shelf.

Home Retail Group, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, MK9 2NW, United Kingdom

700-3024 Issue 1 – R.W. 22-03-10