challenge xtreme

# Electric Stapler and Nailer

**J-123**




Always Read Instruction Manual
Retain for Future Reference

# SAFETY INSTRUCTIONS

To ensure safe operation when using your Electric Stapler & nailer, make sure you follow basic safety principles to reduce risk of personal injury, electric shock, and fire. Please read the following instruction prior to operating this product and keep for future use.

1. **WARNING:**
   This machine is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the machine by a person responsible for their safety. Children should be supervised to ensure that they do not play with the machine.

2. **Guard Against Electric Shock**
   Do not work on or near “live” equipment or services.

3. **Work Environment**
   Work in an area that is not cluttered and has good light.
   Do not expose the Electric Stapler & nailer to direct sunlight, heat, snow or rain.
   .Keep work area clean.

4. **Look after the charger**
   When not in use store in a dry, high place or keep locked up out of children’s reach.
   Use the Electric Stapler & nailer only for its intended purposes.
   Keep all air vents clear to prevent overheating during use.


5. **Protect the Cable**
   Do not carry the Electric Stapler & nailer by the cable or pull the cable to remove the plug from the mains socket.
   Protect the cable from sharp objects,

6. **Disconnect Electric Stapler & nailer**
   When not in use disconnect from mains supply.

7. **Check for damage**
   Before use, check there is no damage to Electric Stapler & nailer

8. **Repairs**
   Always have repairs carried out by a qualified person for your safety.
   There are no user serviceable parts inside the Electric Stapler & nailer.
   If the mains cable become damaged, have repairs carried out by a qualified person.

# COMPONENTS




1. Trigger switch
2. Mains power switch
3. Mains power cord
4. Magazine release lever
5. Magazine
6. Nozzle
7. Anti firing safety switch

**Supplied with:**
Pack of 1000 x 10mm Staples
Pack of 1000 x 15 mm brad nails


**Technical Specifications**

Model No: J-123
Input voltage: 230-240v~50Hz
Class: II
Firing rate: 20/min
Magazine capacity: 100


Staple series: 53
Staple range: 8 - 14mm
Brad nails range: 16 mm - 16 gauge

## Magazine loading


1. Hold the magazine clip with your thumb and fore finger and pull outwards.



2. Insert the staples into the magazine or install the brad nails on the wall of the magazine



3. Push the magazine back into its original position



## Operation

1. Ensure the mains power switch is off and connect to the mains supply

2. Switch the units power switch ON

3. Hold the gun flat against the surface being worked on, ensuring the anti firing safety switch has been pressed down in order for it to activate the gun, pull the trigger to fire the staple / nail into the object being worked on.

4. After completion, switch off, unplug the unit from the mains supply, remove any nails or staples so the unit can be stored away in a safe manor.

## Trouble Shooting

If the Staples / Nails jam, disconnect the unit from the mains supply, release the magazine check & clear the magazine area, reinstall the Staples / nails checking that they are free to move up & down the magazine, push the magazine back into the unit, and start again, if the nails / staples still jam or do not fire into the object being worked on the material may be to hard for nailing or stapling with this type of equipment, and seek professional advise if needed.

## Machine maintenance

With the unit disconnected from the mains supply, clean and check the magazine area for any debris's, apply a few drops of light lubricate around the working area's  then store away.



This symbol is known as the ‘Crossed-out Wheelie Bin Symbol’. When this symbol is marked on a product, it means that the product should not be disposed of with your general household waste. Only discard electrical/electronic items in separate collection schemes which cater for the recovery and recycling of the materials contained within. Your co-operation is vital to ensure the success of these schemes and for the protection of the environment.

This product is guaranteed for domestic use only for a period of 12 months against faulty manufacture or materials.
Any other use may invalidate the guarantee. This product is not guaranteed for hire purposes.
This guarantee does not affect the statutory rights of the consumer.

**NOTE:**
These important safeguards and instructions cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into any product. These factors must be applied by the person using this product

**Argos Ltd**
489 - 499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

7004580_Issue 1304-16_Dongwei