
Toy Storage Unit 3x2

Assembly Instructions - Please keep for future reference

719/0243

719/0250



Dimensions

Width - 126.8 cm

Depth - 43.8 cm

Height - 64.8 cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**

Issue 1 - 29/05/14

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your foor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**


Please check you have all the panels listed below




1 Side x 2
(55x43 cm)



2 Top and Bottom Panel x 2
(126.8x43 cm)



3 Shelf x 3
(40x42.4 cm)






4 Division Panel x 2
(55x43 cm)

Note: Holes drilled through division panel.


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fttings may be supplied than are required.

A  30mm Wooden dowel x 4	B  50mm Wooden dowel x 4	C  50mm Screw x 30
D  Allen key	E  16mm Screw x 16	F  Castor x 4

Tools required




Phillips screwdriver



Small hammer

Ruler- Use this ruler to help correctly identify the screws





Assembly Instructions

Step 1

Insert Wooden dowels Ⓐ into one edge of the Shelf 3 and Wooden dowels Ⓑ into opposite edge.

Repeat with one more shelf.







Step 2

Assemble panels 4, 3 and 1.

Note: Ensure large Wooden dowels Ⓑ fit onto division panel 4 as shown.






Assembly Instructions

Step 3


Assemble panels 4, 3 and 1.

Note: Ensure large Wooden dowels B fit onto division panel 4 as shown.



Step 4

Position the remaining Shelf **3** onto the protruding dowels of the assemblies from steps 2 & 3.




Assembly Instructions

Step 5

Fix side 1 to the assembly using 50mm screws C, tighten using allen key D .

Fix Top panel 2 to the assembly using 50mm screws C, tighten using allen key D.

Please ensure that the pre-mark holes are in the under side of top panel.



C		30
D		1


Step 6

Fix side 1 to the assembly using 50mm screws C , tighten using allen key D.

Fix Bottom panel 2 to

the assembly using 50mm screws C, tighten using allen key D.

Please ensure that the pre-mark holes are in the outside of bottom panel.



Assembly Instructions

Step 7


Attach castors Ⓕ to the Bottom panel [2] using 16mm screws Ⓔ.


Carefully turn the unit over onto the castors.

Warning
The unit is heavy. Lift with care.

Assembly is complete;

Ⓔ		x 16
Ⓕ		x 4





If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**
Avebury, 489-499 Avebury Boulevard, Milton Keynes MK9 2NW.