
Mia - Toy Box

Assembly Instructions - Please keep for future reference

719/3343

719/3350



Dimensions

Width - 80.0cm
Depth - 41.7cm
Height - 47.0cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts,call the **Customer Helpline:08456 400800.**

Issue 1 - 13/10/12

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels 1

If you have damaged or missing componets, call the **Customer Helpline:08456 400800.**


Please check you have all the panels listed below




1 Top panel (80× 41.7cm)




2 Side frame × 2
(45× 40cm)



3 Front panel (68× 40.2cm)



4 Bottom frame (68× 35.8cm)








5 Back panel(68× 37.9cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembiy. In some cases more fittings may be supplied than are required.

A  Ø15×12mm Locking nut × 26	**B**  Ø6×33.5/11mm Locking pin × 26	**C**  Ø8×30mm Wooden dowel × 18
D  Hinge × 2	**E**  Ø3.5×15mm Screw × 12	**F**  Support fitting × 2
G  Ø3.5×15mm Screw × 8		


Tools required



Phillips screwdriver (mendium & large)




Small hammer



Flatblade screwdriver (medium)


Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1


Insert 4 wooden dowels C to Front panel 3 .



Insert 10 wooden dowels C to Bottom frome 4 .




Insert 4 wooden dowels C to Back panel 5 .





Assembly Instructions


Step 2

Insert 26 Locking pins B into 2 Side frame 2 & Front Panel 3 & Back Panel 5 .











Assembly Instructions

Step 3

a: Attach Front Panel [3] and Back Panle [5] to Bottom frame [4] by 8 Locking nuts (A).


a:





b: Attach 2 Side frames [2] to the Unit by using 18 Locking nuts (A).

b:




Assembly Instructions


Step 4

Attaching Top Panel

a: Fix 2 Hinges Ⓓ onto Top panel [1] by using 6 Screws Ⓔ.




b: Fix Top panel [1] to Box Unit by using 6 Screws Ⓔ .



Assembly Instructions


Step 5

Fix Support fitting F to the Box unit by 4 screws G.



Step 6

Assembly is complete .



If you need help or have damaged or missing parts,call the **Customer Helpline:08456 400800.**