REMINGTON®

Sensitive Shaver



GUARANTEE 2yr +1

SF4880

Register online for £10,000 prize draw
EXTRA year guarantee
FREE rewards gallery

Visit www.remington.co.uk/productregister
You must register within 28 days of purchase.

Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe.
Remove all packaging before use.

IMPORTANT SAFETY INSTRUCTIONS

1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
2 Suitable for cleaning under an open water tap.

3 Detach the hand-held part from the supply cord before cleaning in water.
4 Keep the power plug and cord away from heated surfaces.
5 Make sure the power plug and cord do not get wet.
6 This appliance should never be left unattended when plugged into a power outlet, except when charging.
7 Do not use attachments other than those we supply.
8 Do not twist or kink the cable, or wrap it round the appliance.
9 Do not use the appliance if it is damaged or malfunctions.
10 If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.
11 Do not plug or unplug the appliance with wet hands.
12 For use on facial hair only. Not intended for shaving the hair on your head.
13 This appliance is not intended for commercial or salon use.
14 This appliance should be supplied with approved safety isolating adaptors PA-0510E (for Europe), PA-0510K (for United Kingdom) with the output capacity of 5.0 Vdc; 1A (adaptor output).





KEY FEATURES

1 On/Off switch
2 Lifting combs
3 Dual Hybrid intercept trimmers
4 Aloe Vera conditioning bar
5 Charge indicator
6 Shave head
7 Pop-up trimmer
8 Adaptor (not shown)
9 Travel Pouch (not shown)

GETTING STARTED

It is recommended that you use your new shaver daily for up to two weeks to allow time for your beard and skin to become accustomed to the new shaving system.

Your Remington Sensitive Foil shaver has been designed to help reduce irritation and ingrowing hairs for men who experience these conditions when shaving. The lifting combs at both edges of the cutting head help lift flat lying, longer hairs and feed them into the cutters. The shaver is designed to cut hairs at or slightly above the skin surface to help prevent ingrown hairs. For best results, it is recommended to use the shaver daily or every other day to maintain hair length and to reduce ingrowing hairs.

CHARGING YOUR APPLIANCE

Note: It is recommended to fully charge your appliance before using for the first time. Please refer to the charge times shown in this book.

- Ensure the product is switched off.
- Connect the adaptor to the product and then to the mains.

CHARGE LEVEL INDICATORS

Charge Level	Indicator
Charging	LED shows solid green

- Run time from fully charged is up to 45 minutes.
- Charge time from empty is 4 hours.

Note: To preserve the life of your batteries, let them run out every 6 months then fully charge.

INSTRUCTIONS FOR USE

- Make sure your shaver is properly charged.
- Switch the shaver on by pressing the On/Off switch.

SHAVING

- Stretch the skin with your free hand so the hairs stand upright.
- Hold the shaving head so it is in contact with your skin.
- Use short, linear strokes.

TRIMMING

- Slide the trimmer release button down to activate the trimmer.
- Hold the trimmer at a right angle to your skin.
- To retract the trimmer, push the top rear of the trimmer down until it locks under the trimmer release button.

SHAVING WITH SHAVING GEL OR FOAM

- Follow the same instructions as dry shaving if using shaving gel.

Caution: After use with shaving gel, please ensure the head and cutters are rinsed under warm water to clean away any excess gel and debris.

TIPS FOR BEST RESULTS

- Always hold the shaver at right angles to the skin so that the shave head is touching the skin with equal pressure.
- Use moderate to slow stroking movements. The use of short linear motions in stubborn areas may obtain a closer shave, especially along the neck and chin line.
- DO NOT press hard against the skin in order to avoid irritation and damage to the intercept heads.

CARE FOR YOUR SHAVER

- To ensure long lasting performance clean after each use.
- Ensure the appliance is switched off and unplugged from the mains.

DRY CLEANING

- Pull the shave head assembly up to remove from the hair pocket.
- Gently tap out the excess hair shavings and use a cleaning brush to clean out the hair pocket if necessary.
- Do not use a brush to clean the shaving intercept trimmers.
- Replace the head assembly.

WASHABLE CLEANING

- The easiest and most hygienic way to clean the appliance is by rinsing the appliance head after use with warm water.
- Pull the shave head assembly up to remove from the hair pocket.
- Do not use the brush to clean the intercept trimmers but blow the shavings out or rinse in running water.
- Replace the head assembly once dry.
- Lubricate the teeth of the trimmer every six weeks with a drop of sewing machine oil.

REPLACING THE INTERCEPT TRIMMERS & CUTTERS

- To ensure continued high quality performance from your shaver, we recommend the intercept trimmers and cutters are replaced every 12 months.

SIGNS THAT YOUR INTERCEPT TRIMMERS AND CUTTERS NEED REPLACING

- Irritation: as intercept trimmers get worn, you may experience skin irritation.
- Pulling: as the cutters wear, your shave may not feel as close and you may feel the cutter pulling your hair.
- Wear through: you may notice that the cutters have worn through the intercept trimmers

REPLACING THE INTERCEPT TRIMMERS & CUTTERS

- Remove the shave head assembly by grasping the front and back of the shave head and lifting the assembly upwards from the hair pocket.
- Insert the new shave head assembly on the hair pocket, press down and click into place.

- Intercept trimmers and cutters replacement model: SPF-SF4880

BATTERY REMOVAL

- The battery must be removed from the appliance before it is scrapped.
- The appliance must be disconnected from the mains supply when removing the battery.
- Using a small screwdriver, pry off the 2 side panels.
- Using a screwdriver remove the 4 screws from the front of the shaver and remove the front housing.
- Using a screwdriver, remove 8 screws from the front of the shaver.
- Remove and open the core from the shaver to expose the batteries.
- Cut the wires connecting the batteries to the circuit board and remove the batteries.
- The battery is to be disposed of safely.

♲ ENVIRONMENTAL PROTECTION

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled.



➡ SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.
Your statutory rights are not affected.
Consumables are excluded.
Defects from repair by an unauthorized dealer are not covered.
If you call the Service Centre, please have the Model No. to hand, as we won't be able to help you without it. The Model No. can be found on the rating plate of the appliance.
Replacement parts and accessories are available to buy at
www.remington.co.uk/parts-accessories

➡ SERVICE CENTRE

United Kingdom
☎ Tel 0800 212 438 (free call mainland UK)
☎ +44 161 947 3111 (call outside the UK)
Spectrum Brands (UK) Ltd
Fir Street, Failsworth, Manchester
M35 0HS, UK
www.remington.co.uk

Ireland
☎ Tel 142 951 40
Remington Consumer Products,
Unit B12, Ballymount Corporate Park,
Ballymount, Dublin 12.
www.ie.remington-europe.com

REGISTER ONLINE FOR

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.
Visit www.remington.co.uk/productregister. You must register within 28 days of purchase.

Model No. SF4880

17/UK/ SF4880 T22-0004818 Version 02 /17
Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.
Spectrum Brands (UK) Ltd
Fir Street,
Failsworth,
Manchester
M35 0HS
www.remington.co.uk
© 2017 Spectrum Brands, Inc.