
SINGLE BLACK CLOTHES RAIL HEAVY DUTY

Assembly Instructions - Please keep for future reference

735/8865



Dimensions

Width - 150cm Depth - 44cm Height-160.5 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:** Argos = 0345 640 0800

Issue 1 19/10/17

Components - Parts

If you have damaged or missing components,call the Customer Helpline: Argos = 0345 640 0800

Please check you have all the panels listed below

1 Leg tube x 2 (86.4cm)

2 Side tube x 2 (70cm)

3 Hanging rail x 1 (150cm)

2


4 Bottom tube x 1 (150cm)



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Ruler - Use this ruler to help correctly identify the screws

5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

\bigcirc

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

• This is the item with " Maximum loading: 50 kgs", please do not put the weight heavier than 50kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightend properly.

Assembly Instructions

Step 1

Note: It is recommended that two people work together for easier assembly.

a: Insert Caster **(A)** into Leg tube **(1)**.

Repeat Step a: assemble other Leg tube

1 with Caster A.


Note: Please use
Spanner to tighten castors.


b: Insert Bottom tube 4 into Leg tube 1, align both holes on Bottom tube 4 and Leg tube 1, lock by Screw 6 and Nut 0, then tighten by Allen key and Spanner 6.


Repeat Step **b:** assemble other side of Leg tube 1 with Bottom tube 4.

c: Insert Side tube 2 into Hanging rail 3, lock by Flat head screw **3**, then tighten by Allen key **5**.

Repeat Step **c**:
assemble other Side tube
2 with Hanging rail 3.








Assembly Instructions

Step 2

Note: It is recommended that two people work together for easier assembly.

Insert side tube into 2
Leg tube 1.



Assembly is complete.

If you need help or have damaged or missing parts, call the Customer Helpline: Argos = 0345 640 0800