MICROSCALEXTRIC

UK CA CE 9V ⎓

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for advice.

SET INSTRUCTIONS - BATTERY OPERATED

Adult assistance will be required to set up the race track for very young drivers. Read right through these instructions before starting to assemble the race track.

SAFETY NOTES

WARNING: Not suitable for children under 36 months due to:

- Small parts which can present a choking hazard.
- Some components have functional sharp points and edges. Handle with care.

- This product is intended for indoor use only
- Requires 6 x AA Batteries.
- Alkaline batteries recommended. Do not use rechargable batteries.
- Non-rechargeable batteries are not to be recharged.
- Different types of batteries, or new and used batteries are not to mixed.
- Only batteries of same or equivalent type as recommended are to be used.
- Batteries should be replaced by an adult.
- Batteries are to be inserted with the correct polarity, as indicated in the battery powerbase. (See **fig.1**)




fig.1

- Exhausted batteriesare to be removed from the product. Do not dispose of batteries in fire.
- The supply terminals are not to be short circuited.
- Batteries are to be removed from product when not in use.
- The battery powerbase must not be connected to a mains power supply.
- Use only as indicated in the instructions. Do not modify or change any part of the set. Modification may damage the set and will invalidate the warranty claim. Use only genuine Scalextric spares and accessories available from your retailer or www.scalextric.com
- When new, hand controllers may become warm, emit vapour and give off a slight smell. These effects are normal due to protective coating on the internal parts and will disappear after use. However, these effects may return if the trigger is held continuously in a fixed position while racing.
- Before cleaning any part, remove batteries. Do not use liquid for cleaning.
- Please retain these details and the address for future reference.

⚠ **WARNING: CHOKING HAZARD** Small parts. Not for children under 3 years.	
AGE 3 WATCH WITH ADULT SUPERVISION **AGE 4-7 OPERATE WITH ADULT SUPERVISION**	**AGE 3+**


⚠ **DANGER: RISQUE DE SUFFOCATION** Petites pièces. No convienient pas aux enfants de mois de 3 ans.	
AGE 3 REGARDER SOUS LA SUPERVISION D'UN ADULT **AGE 4-7 A UTILISER SOUS LA SUPERVISION D'UN ADULT**	**AGE 3+**

RACING INSTRUCTIONS


- Speed of the car is controlled by the hand controller trigger. The more you squeeze the trigger the faster the car will go.
- Slow down for the bends by releasing the trigger.
- If the car is going too fast on the bend it will fly off the track.

GETTING STARTED


1 Make up the race track by carefully identifying the different track sections in the track diagram from illustrated contents list. Push the track sections firmly together in a straight line.




2 Make sure the sections are fully clipped together.




3 Fit the track supports to make a bridge in the race track.




4 When the race track is completely assembled, connect up the hand controllers and insert 6 x AA batteries into the power base.



5 Place a car in one side of the track with its guide blade in the slot between the metal rails. Slowly squeeze the trigger of hand controller connected to the lane the car is on to make the car slowly go round the track. Now put the other car on the other lane and use the other hand controller to test it.If both cars work on both lanes of the track, you are ready to race. Remember, the more you squeeze the trigger, the faster the cars will go, so take it easy at first!




6 For Beginners the movement of the trigger can be restricted by sliding the button on the underside of the handle. There are 4 setting available which will limit the maximum power to either 25%, 50%, 75% or 100%.




TAKING THE TRACK APART

! When dismantling the race track, pull the track sections apart in a straight line.




CHANGING THE BRAIDS & CAR MAINTENANCE


1 If the cars do not run, the braids may need cleaning, bending towards the track or the whole guide blade may need changing. To change the guide blade, turn the car over and unscrew the guide blade from the chassis.




2 Remove the guide blade from the chassis.



3 Fit the new guide blade to the chassis by engaging the back clip first and then screwing in the front post.




4 Remove any carpet fibres, pet hairs etc., from around the car's axles and gear wheels. This will make the car run more efficiently and smoothly.




TRACK MAINTENANCE


1 Always keep the track clean by wiping over with a non-fluffy cloth, especially before putting the set away. Keep the pick-up rails shiny by carfully rubbing with a nylon washing-up pad or track cleaning rubber.



2 Keep the slot between the pick-up rails free from anything which would prevent the guide blade from travelling along it freely.



3 Make sure anything made of metal does not bridge the two pick-up rails which would cause a short-circuit.




SPARE PARTS

Please contact us for spare parts.

For full list of contents please refer to the set specific instruction sheet which can be found inside your set pack.

All sets come with the following spare parts:



Guide Blade x 2

Spare Part No. W11189

CONTACT US

CONTACT US

If you have a question that has not been answered in this leaflet, then please contact Scalextric Customer Services using any of the following method:

E-Mail: **customerservices@scalextric.com**

Phone: **+44 (0) 1843 233525**

Website: **www.scalextric.com**

Scalextric products are guaranteed against defects in materials or

workmanship for a period of six months from purchace. If any such defect occurs during the period of warranty, please contact our customer services team by visiting our website.

LIMITED 90-DAY WARRANTY - USA & CANADA

This warranty applies only to products purchased and used in the United States or Canada.

To activate your warranty, please complete and return the registration card included with your set within 30 days of purchasing this product. Please retain this warranty and you receipt of purchase from and authorized Scalextric dealer.

If the mechanisms of this product are found to be defective in materials or workmanshipwithin 90 days from the date of purchase, Scalextric Motorsport shall undertake to either repair or replace the defective product free of charge. The decision whether to repair or replace the defective product is made by Scalextric Motorsport Ltd. at its sole discretion.

This warranty applies only for private non-commercial use by the original registered purchaser. Tamper, accident, abuse, negligence, unauthorized repairs or other causes, unrelated to defective materials or workmanship, will void this warranty. This warranty does not cover consumable parts.

The rights specified in this warranty shall be the sole and exclusive remedy of the purchaser for any claim under the warranty. Implied warranties, including the implied warranty of merchantability, are limited in duration to a 90 day period from date of purchase and are subject to the conditions set out herein. Scalextric Motorsport is not liable for incidental or consequential damages resulting from the breach of any express or implied warranties.

While this waranty gives you specific legal rights, you may also have other rights which vary state to state.

The answer to many technical questions can be found on the Scalextric website

Please ensure that you have read the user instructions carefully

If you still have an issue please contact us via the E-mail or Telephone number in the contact us section above.

If our service representative is unable to resolve the problem by telephone or E-mail, you may be instructed to return the product, (freight prepaid) with your full details to the address in the contact us section.

Prior Authorization by Scalextric Motorsport Ltd. must be granted before returning any product. The repaired or replaced item will be returned to you frieght prepaid (USA and Canada Only) or made available to you for pick up at a convenient Scalextric dealer.

LIMITÉ 90-JOUR WARRANTY - ÉTATS-UNIS & CANADA

Cette garantie concerne uniquement les produits achetés et utilisés aux États-Unis ou au Canada.

Pour valider votre garantie, veuillez remplir et retourner la fiche d'instruction qui se trouve avec le produit, dans un délai de 30 jours à compterde sa date d'achat. Veuillez conserver cette garantie ainsi que votre preuve d'achat d'un concessionnaire agréé de Scalextric.

Si les mécanismes de ce produit s'avèrent défecteueux, que ce défaut provienne de matériaux défectueux ou d'une malfaçon au cours de la période de 90 jours suivant la date d'achat, Scalextric Motorsport s'engage, à réparer ou à remplacer gratuitement le produit défectueux. La décision de réparer ou de remplacer le produit défectueux sera prise par Scalextric MotorsportLtd. à son entière discrétion.

La présente garantie concerne uniquement l'utilisation privée et non-commerciale du produit, par l'acheteur original enregistré. Les altérations, accidents, abus, négligences, réparations non autorisées ou autres causes sans rapport avec des matériaux défectueux ou une mafaçon, annuleront cette garantie. Cette garantie ne couvre pas les consommables.

Les droits indiqués dans cette garantie sont les seuls et exclusifs recours de l'acheteur de faire une réclamation en vertu de la garantie. Les garanties implicites, y compris la garantie implicite de qualité marchande, sont limitées à une période de 90 jours à compter de la dat d'achat et sont sous réserve des conditions de présentes.

Scalextric Motorsport décline toute responsabilité quant aux dommages accessoires ou immatérials découlant de la violation de toute garantie explicite ou implicite.

Bien que cette garantie vous confère des droits spécifiques vis-à-vis de la loi, il est possible que vous bénéficiiez d'autres droits, qui seront différents d'un état à un autre et d'une province à une autre.

On trouvera la réponse à de nombreuses questions techniques sur le site web de Scalextric

Assurez-vous de prendre connaissance des instructions d'utilisation.

Si le problème persiste, n'hésitez pas à nous contacter au numéro de téléphone ou adresse de courriel indiqué à la section Contactez-nous ci-dessus.

Si notre représentant n'est pas en mesure de résoudre le problème par téléphone ou par courriel, on pourra vous demander de renvoyer le produit (fret payé d'avance), avec vos coordonnées complètes à l'adresse indiqué dans la section Contactez-nous.

Avant de retourner un produit, vous devez obteiner l'autorisation préalable de Scalextric Motorsport Ltd. L'article réparé ou remplacé vous sera renvoyé, fret payé d'avance (uniquement pour les États-Unis et le Canada) ou bien il sera disponible chez un Concessionaire Scalextric près de chez vous.

Manufactured By: Scalextric Motorsport Ltd, Westwood, Margate, Kent, CT9 4JX, UK
EU Authorised Representative: Hornby Italia SRL Viale dei Caduti, 52/A6, Castel Mella (BS), Italy, 25030
US Address: Professor Motor INC, 1235 Industrial Drive STE #10, Saline, MI 48176-1742

Instruction Leaflet No. PI-01030