

White Mirror Double Door Cabinet

Simple Assembly Instructions - **Please keep for future reference**




Components


Ⓐ 1 x Back Panel



Ⓓ 1 x Left Door




Ⓔ 1 x Right Door




Ⓘ 8 x Screw Cover




Ⓙ 4 x Shelf Support




Ⓚ 4 x Door Hinge




Ⓑ 1 x Left Side Panel




Ⓒ 1 x Right Side Panel



Ⓕ 1 x Bottom Panel



Ⓛ 2 x Plastic Plate




Ⓖ 1 x Shelf



Ⓗ 1 x Top Panel



Ⓜ 2 x Door Stopper




Fittings

Ⓐ 12 x Screw



Ⓑ 4 x Wall Plug



Ⓒ 16 x Screw



Ⓓ 8 x Screw



4-04

IMPORTANT

1. *Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.*
2. *Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.*
3. *Take all the fittings out of the plastic bag and separate them into their groups.*
4. *Ensure you have enough space to lay out all the parts before assembly.*
5. *To avoid scratching it is recommended that you assemble the unit on a soft level surface.*

Assembly Instructions

Stage 1 – Fitting the Side Panels

BS 7449:1991
Model / Catalogue Number: 832/0005
Retailer: ARG
Retailer address:
489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, Bucks, MK9 2NW

NOTE: This unit contains film backed glass of nominal thickness of 4mm. If the glass is chipped or broken, replace with glass of the type described on this label. Consult the furniture retailer or agent with regard to obtaining a manufacturing specification of the shape for replacement glass quoting the model number, and batch number or date of manufacture of this item.

NOTE: There are many different kinds of Screws and Panels. Ensure you check before assembly.

1. Use Screws Ⓓ to fix Plastic Plates Ⓛ onto the Bottom Panel Ⓕ.
   See fig. 1.

2. Use Screws Ⓐ to fix Left Side Panel Ⓑ and Right Side Panel Ⓒ onto the Bottom Panel Ⓕ. Then use Screw Covers Ⓘ to cover the screws.
   See fig. 2.

NOTE: Ensure the grooves on Side Panel Ⓑ, Ⓒ and Bottom Panel Ⓕ are aligned.

3. Slide the Back Panel Ⓐ into the unit.
   See fig. 3.




fig. 1




fig. 2




fig. 3

Assembly Instructions

Stage 2 – Fitting the Top Panel

1. Use Screws Ⓐ to fix Top Panel Ⓗ onto the unit. Then use Screw Covers Ⓘ to cover the screws.
   See fig. 4.




fig. 4

2. Use Screws Ⓒ to fix the Door Hinges Ⓚ onto the unit.
   See fig. 5.




fig. 5

CAUTION: When handling glass always take extra care. Ensure no children are in the assembly area.

3. Use Screws Ⓓ to fix the Door Stoppers Ⓜ onto Left Door Ⓓ and Right Door Ⓔ.
   See fig. 6.




fig. 6

Assembly Instructions

Stage 3 – Fitting the Shelf

1. Use Screws Ⓒ to fix the Left Door Ⓓ and Right Door Ⓔ onto the unit.
   See fig. 7.

2. Place the Shelf Supports Ⓙ into the unit.
   See fig.8.

NOTE: Adjust the shelf supports to the desired height.

3. Slide the Shelf Ⓖ into the unit.
   See fig. 9.

WARNING:

- **Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.**
- **Do not strike the glass with hard or pointed items.**
- **When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substance containing abrasive since these substances scratch glass.**




fig. 7




fig. 8




fig. 9

Assembly Instructions

Stage 4 – Wall Mounting


NOTE: It would be useful to ask someone to help you at this stage.

IMPORTANT: When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs supplied are suitable for supporting the unit. Consult a qualified tradesperson if you are not sure.

WALL MOUNTING: Hold the unit against the wall in the desired location and check if it is horizontal. Mark the wall to indicate where to drill the holes. See fig. 10.

1. Use the Wall Plugs Ⓑ to fit to the holes. Then screw in the Screws Ⓐ through the unit into the Wall Plugs.
   See fig. 11.

NOTE: Before use always make sure the unit is secure.


fig. 10





fig. 11


fig. 12

Care and Maintenance


Safety
To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning
As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.


Fitting
From time to time please ensure there are no loose screws on the product.

White Mirror Double Door Cabinet


Simple Assembly Instruction - Please keep for future reference



Component Parts




A. Top Panel x 1




B. Bottom Panel x 1




C. Adjustable Shelf x 1




D. Left Side Panel x 1




E. Right Side Panel x 1



F. Left Door x 1




G. Right Door x 1



H. Back Panel x 1

Fittings



I. Door Hinge x 4




J. Hinge Screw x 16



K. Shelf Support x 4



L. Door Catch x 2



M. Catch Plate x 2



N. Catch Screw x 8



O. Assembly Screw x 8



P. Screw Cap x 8



Q.Wall Plug x 4



R. Wall Screw x 4

IMPORTANT

1.Read these instructions carefully and familiarize yourself with the procedure before assembling the unit

2.Check that your have all component parts and fittings required these are listed on the back of this guide .

3.Take all the fitting out of the plastic bag and separate them into their groups.

4.Ensure you have enough space to lay out all the parts before assembly

5. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

Assembly Instructions

Stage 1 - Fitting the Side Panels

NOTE: This unit contains film backed mirror of nominal thickness of 4 mm, which is not required to be classified to BS6206 Class C.If a glass is chipped or broken replace with glass of the type described on this label. Consult the manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch number or date of manufacture of the table.

NOTE: There are many different kinds of Screws and Panels . Ensure you check before assembly.

1.Use catch screw (N) to fix the catch plate (M) onto the top panel (A). (See Fig. 1)




Fig. 1

2. Attach left & right side panels (D&E) to the top panel with assembly screw (O).Then use the screw caps (P) to cover the screw holes . (See Fig. 2)




Fig. 2

NOTE: Ensure the grooves on the side panel (D&E) , and top panel (A) are aligned.

3. Slide the back panel (H) into the unit . (See Fig. 3)




Fig. 3

Assembly Instructions

Stage 2 - Fitting the Top Panel

4. Attach bottom panel (B) to the unit with assembly screw (O). Then use the screw caps (P) cover the screw holes . (See Fig. 4)




Fig. 4

5.Attach the door hinge (I) to the unit with hinge screw (J). (See Fig. 5)

CAUTION: When handling glass always take extra care. Ensure no children are in the assembly area.




Fig. 5

6.Attach door catch (L) to the left & right door (F&G) with catch screw (N). (See Fig. 6)




Fig. 6

Assembly Instructions

Stage 3 - Fitting the Doors and Shelf

7.Attach the left & right door (F&G) to the unit by door hinge (I) with hinge screw (J). (See Fig. 7)

8.Place the shelf supports (K) into the unit . Then put the adjustable shelf (C) onto it. (See Fig. 8)

NOTE: You can adjust the shelf supports to the desired height.




Fig. 7




Fig. 8

WARNING:

*** Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.**
*** Do not strike the glass with hard or pointed items.**
*** When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substance containing abrasive since these substances scratch glass.**

Assembly Instructions

Stage 4 - Wall Mounting & Fixings

NOTE: It would be useful to ask someone to help you at this stage.
IMPORTANT: When drilling into walls always check that there are no hidden wires or pipes ect. Make sure that the screws and wall plugs supplied are suitable for supporting the unit. Consult a qualified tradesperson if you are not sure.
WALL MOUNTING: Hold the unit against the wall in the desired location and check if it is horizontal. Mark the wall to indicate where to drill the holes .

9. Use the wall plugs() to fit to the holes.Then screw in the wall screws through the unit into the wall plugs. (See Fig. 9)

NOTE: Before use always make sure the unit is secure.




Fig. 9




Fig. 10

Care and Maintenance

SAFETY

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

CLEANING

As with all surfaces clean with a damp cloth and mild detergent , do not use bleach or abrasive products.

FITTING

From time to time please ensure there are no loose screws on the product.

SAFETY WARNING INFORMATION

BS7449 : 1991

Keep these instructions for future use:

Catalogue Number: 832-0005 (D)

Manufacture date:

Retailer: **Argos**

Retailer address: **489-499 Avebury Boulevard**
Saxon Gate West
Central Milton Keynes
Bucks, MK9 2NW

WARNINGS

*Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.

This unit contains film backed mirror of nominal thickness of **4** mm, which is not required to be classified to BS6206 Class C.

*Do not strike the glass with hard or pointed items.

If a glass is chipped or broken replace with glass of the type described on this label. Consult the manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch number or date of manufacture.

* Do not sit or stand upon horizontal glass surfaces.


*When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substance containing abrasive since these substances scratch glass.

*It is essential that this unit is fixed to a wall with the fixings provided.

A Guide to
Wall Mounting & Fixings

IMPORTANT:

When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.




HINTS:

1) General Rule ⚠ Always use a larger screw and wall plug if you are not sure.
2) Ensure you use the recommended drill bit to match the wall plug and hole size.
3) Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4) Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure the plug is fitting below the ceramic tile to avoid splitting or cracking.
5) Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types Of Walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone, wood or plaster board.

No.1 "Standard" Wall Plug
General Wall Materials



These come in various sizes and are made from plastic or sometimes wood fiber.


No.2 "General Purpose" Wall Plug
Aerated / Breeze Block



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case.
For light loads, a General Purpose Plug can be used.


A Guide to
Wall Mounting & Fixings

No.3 "Shield Anchor" Wall Plug
Heavy Loads




For use with heavier loads such as TV & HiFi Speakers and Satellite Dishes etc.

No.4 "Cavity Fixing" Wall Plug




For use with plaster board partitions or hollow wooden doors.

No.5 "Cavity Fixing - Heavy Duty" Wall Plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets, coat racks.

No.6 "Hammer Fixing" Wall Plug



For use with walls stuck with plaster board. The hammer fixing allows it to be fixed to the wall rather than the plaster board. Always check the fixing is secure to the retaining wall.

CARE & MAINTENANCE

⚠ **SAFETY**


Always check the fitting and location to ensure your safety in and around the home.

⚠ **FITTING**

From time to time check the fitting to ensure the wall plugs or screws do not become loose.

White Mirror Double Door Cabinet

Assembly Instructions – Please keep for future reference | 832/0005



Dimensions

Width - 60cm
Depth - 18cm
Height - 50cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Issue 1 - 03/22/12

Safety and care advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on page 2 .

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels, this could cause damage.

• Assemble the unit as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• ***Note:*** Only apply the glue once you are sure of the assembly.

• The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.

• Parts of the assembly will be easier with 2 people.

• If using power tools, please follow the safety instructions supplied with the tools.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• ***Warning:*** Before drilling, check the wall for hidden pipes and cables.

• Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the Customer Helpline:08456 400800


Please check you have all the panels listed below




1 Top Panel x 1




2 Bottom Panel x 1




3 Adjustable Shelf x 1



4 Left & Right Side Panel x 2



5 Back Panel x 1








6 Left & Right Door x 2


Components - Fittings

Please check you have all the fittings listed below

Note:The quantities below are the correct amount to complete the assembly .In some cases more fittings may be supplied than are required.

A  Hinge x 4	B  12mm Screw x 20	C  30mm Screw x 8
D  Plastic Support x 4	E  Strike Plate x 2	F  Magnetic Catch x 1
G  Wall Plug(for solid wall only) x 4	H  45mm Screw x 4	I  Screw Cap x 8

Tools required




Phillips screwdriver (medium & large)

7mm Suitable drill bit (for use with wall plug)




Ruler/tape measure



Drill




Small hammer



Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Assembling top,lelf side and bottom panels

NOTE:It would be useful to ask someone to help you at this stage.


a:Attach hinges Ⓐ to the left & right side panels [4] with 12mm screws Ⓑ

b:Attach magnetic catch Ⓕ to the top panel [1] with 12mm screws Ⓑ


c:Use 30mm screws Ⓒ to fix top panel [1] and bottom panel [2] into left side panel [4]

Please make sure the grooves on each panel are aligned.


a:



b:



c:




Step 2

Assembling back and right side panel

Carefully slide the back panel [5] into the grooves of panels [1] [2] and left side panel [4]

Attach right side panel [4] to the unit with 30mm screws Ⓒ



Assembly Instructions


Step 3

Assembling door

NOTE:It would be useful to ask someone to help you at this stage.

Use 12mm screws B to fix strike plate E on the left & right door panels 6


Carefully attach left & right door panels to the unit with door hinges A by 12mm screws B



Step 4

Fixing the screw caps

Insert the screw caps I over the screw holes on the outside.




Assembly Instructions

Step 5

Fixing to the wall

NOTE:It would be useful to ask someone to help you at this stage.

Use 45mm screws Ⓗ and wall plugs Ⓖ to fix the unit on the wall.



Step 6

Assembling adjustable shelf panel


NOTE:It would be useful to ask someone to help you at this stage.

Insert plastic supports Ⓓ into side panels 4

Carefully put the adjustable shelf panel 3 on it.

NOTE: Please make sure the unit is secure before use.

The assembly is now complete.



NOTE:If you have damaged or missing components,
call the Customer Helpline:08456 400800
Home Retail Group,489-499 Avebury Boulevard,
Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.


Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.

White Mirror Double Door Cabinet

Assembly Instructions – Please keep for future reference | 832/0005



Dimensions

Width - 60cm
Depth - 18cm
Height - 50cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Issue 2 - 8/23/12

Safety and care advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on page 2 .

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels, this could cause damage.

• Assemble the unit as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• ***Note:*** Only apply the glue once you are sure of the assembly.

• The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.

• Parts of the assembly will be easier with 2 people.

• If using power tools, please follow the safety instructions supplied with the tools.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• ***Warning:*** Before drilling, check the wall for hidden pipes and cables.

• Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the Customer Helpline:08456 400800


Please check you have all the panels listed below




1 Top Panel x 1




2 Bottom Panel x 1




3 Adjustable Shelf x 1



4 Left & Right Side Panel x 2



5 Back Panel x 1







6 Left & Right Door x 2


Components - Fittings

Please check you have all the fittings listed below

Note:The quantities below are the correct amount to complete the assembly .In some cases more fittings may be supplied than are required.

A  Hinge x 4	B  12mm Screw x 20	C  30mm Screw x 8
D  Plastic Support x 4	E  Strike Plate x 2	F  Magnetic Catch x 1
G  Wall Plug(for solid wall only) x 4	H  45mm Screw x 4	I  Screw Cap x 8

Tools required




Phillips screwdriver (medium & large)

7mm Suitable drill bit (for use with wall plug)




Ruler/tape measure



Drill




Small hammer



Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Assembling top,lelf side and bottom panels

NOTE:It would be useful to ask someone to help you at this stage.


a:Attach hinges Ⓐ to the left & right side panels [4] with 12mm screws Ⓑ

b:Attach magnetic catch Ⓕ to the top panel [1] with 12mm screws Ⓑ


c:Use 30mm screws Ⓒ to fix top panel [1] and bottom panel [2] into left side panel [4]

Please make sure the grooves on each panel are aligned.


a:



b:



c:




Step 2

Assembling back and right side panel

Carefully slide the back panel [5] into the grooves of panels [1] [2] and left side panel [4]

Attach right side panel [4] to the unit with 30mm screws Ⓒ



Assembly Instructions


Step 3

Assembling door

NOTE:It would be useful to ask someone to help you at this stage.

Use 12mm screws Ⓑ to fix strike plate Ⓔ on the left & right door panels 6


Carefully attach left & right door panels to the unit with door hinges Ⓐ by 12mm screws Ⓑ



Step 4

Fixing the screw caps

Insert the screw caps Ⓘ over the screw holes on the outside.




Assembly Instructions

Step 5

Fixing to the wall

NOTE:It would be useful to ask someone to help you at this stage.

Use 45mm screws H and wall plugs G to fix the unit on the wall.



Step 6

Assembling adjustable shelf panel


NOTE:It would be useful to ask someone to help you at this stage.

Insert plastic supports D into side panels 4

Carefully put the adjustable shelf panel 3 on it.

NOTE: Please make sure the unit is secure before use.

The assembly is now complete.



NOTE:If you have damaged or missing components, call the Customer Helpline:08456 400800
Argos LTD,489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.