


MONKS BENCH LAUNDRY BOX


Please note the groove in part C is wider than the groove in part B


WARNING-Keep small parts away from children. Do not allow children to climb on this product.























STEP 8:




STEP 9:





STEP 11:




Assembly Instructions

Step 12

Screw the right side panel 6 the ends of the rails using 5 x 40mm screw 6 as shown.

Ensure that the righthand hinge of the lid is properly located in its hole in the right side panel.



Step 13

Drop the base panel 9 onto the bottom rails inside the unit.

Step 14


Lift the lid and connect the hinge **F** to the lid and the top back rail as shown using 4 x 12mm screw **G**.



Important:
The hinge
must must be
attached the
correct way up.

Please pay attention to diagram **a:** for correct installation.

Assembly complete.



If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800

Monk's Bench Style Linen Bin

Assembly Instructions- please keep for future reference

832/5299



Dimensions

Width - 55cm Depth - 35cm Height - 58cm

THIS PRODUCT IS NOT DESIGNED OR INTENDED AS A TOY STORAGE CONTAINER

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800

LP 255.96.774



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 1 and 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.


• Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- · From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




Components - Fittings If you have damaged or missing components, call the Customer Helpline: 0845 640 0800

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools required




Ruler – Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions


Step 1

Insert 2 x connector A into the holes in the front top rail 1 as shown.




Step 2

Insert 2 x connector A into the holes in the bottom back rail 2 as shown.



Step 3

Insert 2 x connector A into the holes in the bottom front rail 3 as shown.




Step 4

Insert 4 x connector A into the holes in the top back rail 4 as shown.

Step 5

Insert 4 x 30mm dowel C into the left side panel 5 and right side panel 6 as shown.



Assembly Instructions

Step 6

Screw both the hinges

to the lid 10 using 4

x 12mm screw 6.

Important: the hinge must fit flush to the edge of the lid (a:). If the hinge post protrudes from the lid as shown (b:), the lid will not fit the linen bin.


Important: when fitting metal hinges to lid, fit both screws before tightening either of them.

Step 7

Screw the top back rail 4 and the bottom back rail 2 to the left side panel 5 using 3 x 40mm screw B.

Step 8

Slide the back panel 7 into the slots of the two back rails.




Assembly Instructions

Step 9


Screw the top front rail

1 and the bottom
front rail
3 to the left
side panel
5 using 2 x
40mm screw
6.



Step 10

Slide the front panel 8 into the slots of the two front rails.



Step 11

Slot the left-hand hinge of the lid 10 into the hole provided on the inside of the left side panel.

