

3 DOOR MIRROR DOOR CABINET

056.96.095


WARNING: Keep small parts away from shildren.
Do not allow children to climb on this product.
www.lloydpascal.co.uk

ASSEMBLY INSTRUCTION







(1)





(2)




(3)















(4) (5) (6)

					
A 1x	B 1x	C 1x	D 2x	E 1x	F 3x
					
G 1x	H 3x	a 2x	b 2x	c 2x	d 16x
					
e 3x	f 6x	g 3x	h 3x	i 6x	j 2x

HELPLINE: IF YOU REQUIRE ANY FURTHER ASSISTANCE WITH THIS PRODUCT, PLEASE EMAIL VIA THE WEBSITE
www.lloydpascal.co.uk
OR RING THE FOLLOWING NUMBER ASKING FOR CUSTOMER SERVICES 00 44 (121) 753 7720

Traditional 3 Door White Cabinet

Assembly Instructions – Please keep for future reference | 832/8832



Dimensions

Width - 76cm
Depth - 17cm
Height - 41cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Issue 2 - 08/23/12

Safety and care advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels, this could cause damage.

• Assemble the unit as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• ***Note:*** Only apply the glue once you are sure of the assembly.

• The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.

• Parts of the assembly will be easier with 2 people.

• If using power tools, please follow the safety instructions supplied with the tools.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• ***Warning:*** Before drilling, check the wall for hidden pipes and cables.

• Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the Customer Helpline:08456 400800


Please check you have all the panels listed below




1 Top Panel x 1




2 Bottom Panel x 1




3 Back Support x 1




4 Left Side Panel x 1




5 Right Side Panel x 1




6 Middle Panel x 2




7 Left Door x 1



8 Right Door x 2



9 Back Panel x 3















10 Adjustable Shelf x 3


Components - Fittings


Please check you have all the fittings listed below

Note:The quantities below are the correct amount to complete the assembly .In some cases more fittings may be supplied than are required.


A  Wooden dowel x 4	B  Locking Pin x 2	C  Locking Nut x 2
D  Shaft x 6	E  Knob x 3	F  25mm Screw x 3
G  35mm Screw x 16	H  12mm Screw x 6	I  10mm Screw x 15
J  Strike Plate x 3	K  Magnetic Catch x 3	L  Screw Cap x 16
M  Plastic Support x 12	N  45mm Screw x 2	O  Wall plug(for solid walls only) x 2

Tools required


Phillips screwdriver (medium & large)



Flatblade screwdriver (medium)

7mm Suitable drill bit (for use with wall plug)



Drill


Small hammer


Ruler/tape measure


Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Assembling side panels

a:Insert locking pins Ⓑ into left side panel 4 and right side panel 5

b:Insert locking nuts Ⓒ and wooden dowels Ⓐ into back support 3, attach side panels 4 5 to back support panel and turn the locking nuts clockwise to lock the unit.



Step 2


Assembling back panels

NOTE:It would be useful to ask someone to help you at this stage.

a:Carefully place the middle panel 6 onto the unit and slide the back panel 9 into the grooves of left side panel 4 and middle panel.

b:Carefully place the other middle panel 6 onto the unit and slide the back panel 9 into the grooves of two middle panels.

c:Carefully slide the back panel 9 into the grooves of right side panel 5 and middle panel 6




Assembly Instructions

Step 3

Assembling bottom panel

Use 35mm screws G to fix bottom panel 2 to the unit.

Insert the screw caps L over the screw holes on the outside.



Step 4

Assembling door


NOTE:It would be useful to ask someone to help you at this stage.

a:Use 10mm screws I to fix door shafts D on the left door panel 7 and right door panel 8

Use 10mm screws I to fix strike plates J on left & right door panel.

Use 25mm screws F to fix knobs E onto left & right door panel.


a:



b:Insert wooden dowels A into back support panel 3

Carefully insert left door panel 7 and right door panels 8 into bottom panel 2

b:



Assembly Instructions

Step 5


Assembling top panel

a:Attach magnetic catches Ⓚ to the top panel [1] with 12mm screws Ⓗ


b:Use 35mm screws Ⓖ to fix top panel [1] onto the unit.

Insert the screw caps Ⓛ over the screw holes on the outside.

a:



b:




Step 6

Fixing to the wall

NOTE:It would be useful to ask someone to help you at this stage.

Use 45mm screws Ⓝ and wall plugs Ⓞ to fix the unit on the wall.



Step 7

Assembling adjustable shelves


NOTE:It would be useful to ask someone to help you at this stage.

Insert plastic supports Ⓜ into side panels [4] [5] and middle panels [6]

Carefully put the adjustable shelf panel [10] on it.

NOTE: Please make sure the unit is secure before use.

The assembly is now complete.



NOTE:If you have damaged or missing components, call the Customer Helpline:08456 400800
Argos LTD,489-499 Avebury Boulevard,
Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.