
SINGLE MIRROR DOOR CABINET


056.96.093

WARNING: Keep small parts away from shildren.
Do not allow children to climb on this product.
www.lloydpascal.co.uk


ASSEMBLY INSTRUCTION




(1)




(2)




(3)






(4)



(5)



(6)


					
A 1x	B 1x	C 1x	D 1x	E 1x	F 1x
					
G 1x	a 2x	b 2x	c 2PCS	d 8x	e 1x
					
f 2x	g 1x	h 1x	i 2x	j 2x	

HELPLINE: IF YOU REQUIRE ANY FURTHER ASSISTANCE WITH THIS PRODUCT, PLEASE EMAIL VIA THE WEBSITE
www.lloydpascal.co.uk
OR RING THE FOLLOWING NUMBER ASKING FOR CUSTOMER SERVICES 00 44 (121) 753 7720

Wall Cabinet

Assembly Instructions- please keep for future reference

832/8904



Dimensions

Width - 25cm
Depth - 13cm
Height - 44cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 1 - 05/05/10

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 1 and 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance


• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




1 Top x 1
(25(w)cm x 13(d)cm)




2 Bottom x 1
(25(w)cm x 13(d)cm)



3 Left side x 1
(41.6(h)cm x 10.5(d)cm)




4 Right side x 1
(41.6(h)cm x 10.5(d)cm)




5 Rail x 1
(5(h)cm x 20(w)cm)



6 Back x 1
(37.3(h)cm x 20.6(w)cm)



7 Door x 1
(41.2(h)cm x 22.5(w)cm)












8 Shelf x 1
(20(w)cm x 9(d)cm)

Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  30mm Screw x 8	**B**  30mm Wooden dowel x 4	**C**  25mm Screw x 1	**D**  Knob x 1
E  Magnetic catch x 1	**F**  14mm Screw x 2	**G**  Hinge x 2	**H**  10mm Screw x 4
I  Shelf bracket x 4	**J**  Screw cover x 8	**K**  35mm Screw x 2	**L**  Rawl plug x 2

Tools required




Phillips screwdriver (medium & large)



Drill


Ruler – Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Insert magnetic catch **E** to under side of top **1** using 2 x 14mm screw **F** as shown.



Step 2


Insert 4 x 30mm wooden dowel **B** into rail **5** as shown.



Step 3


Connect 2 x hinge **G** to door **7** using 4 x 10mm screw **H** as shown.

Connect knob **D** to door **7** using 25mm screw **C** as shown.



Step 4


Connect rail **5** to left side **3** and right side **4** as shown.



Assembly Instructions

Step 5


Turn the unit over and slot back [6] into place as shown.



Step 6

Connect bottom [2] to the unit using 4 x 30mm screw (A) as shown.

Cover each of the screw heads with 1 x screw cover (J).




Assembly Instructions

Step 7

Turn the unit right way up and slot the hinges of door [7] into place.

Lock the door hinges in place by connecting top [1] to the unit using 4 x 30mm screw Ⓐ as shown.

Cover each of the screw heads with 1 x screw cover Ⓙ.



Step 8

Mount the unit on a wall using 2 x 35mm screw Ⓚ and 2 x rawl plug Ⓛ throught the rail as shown.


Note: see the back cover for more information on wall mounting and the suitable use of the supplied rawl plugs.

Warning:
Before drilling, check wall for hidden pipes and cables.

Insert 4 x shelf bracket Ⓘ into the holes inside the unit at the desired height.

Set shelf [8] onto the shelf brackets.

Assembly complete.



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 “General Purpose” wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 “Cavity Fixing” wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 “Hammer Fixing” wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 “Plasterboard” wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 “Cavity Fixing – Heavy Duty” wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 “Shield Anchor” wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**