
Triple Mirrored Door Cabinet

Simple Assembly Instructions - Please keep for future reference

Components



A. Left Side Panel x 1

B. Right Side Panel x 1

C. Left Internal Panel x 1

D. Rignt Internal Panel x 1

E1. S Shelf x 4

E2. L Shelf x 2

F. Top Panel x 1


G. Base Panel x 1

H. Back Panel x 1


I. Left Door x 1

J. Middle Door x 1

K. Right Door x 1



Fittings



L. Screw Cap x 16

M. Shelf Support x 24

N. Straight Hinge x 4

O. Hinge Screw x 36

P. Curving Hinge x 2

Q. Triangle Board x 4

R. Wall Plug x 4

S. Wall Screw x 4

T. Assembly Screw x 16

IMPORTANT

1. Familiarise yourself with the procedure before assembling the unit.
2. Check that you have all the component parts following the list on the BACK cover and familiarise yourself with each part before proceeding.
3. Take all the fittings out of the plastic bag and separate them into their groups.
4. Ensure you have enough space to lay out all the parts before assembly.
5. To avoid scratching it is recommended that you assemble the article on a soft level surface.
6. The Maximum Safe Load of this item is 10KGS

Assembly Instructions

Fitting the Support Frame

NOTE: It would be useful to ask someone to help you to assemble this unit.

1. Attach the side panel(A&B) and internal panel (C&D) to base panel (G) with assembly screw (T).
   (See Fig. 1)

   Ensure that the grooves in the side panels face inwards and are aligned with the groove in the base panel.

2. Insert the back panel (H) by sliding it into the grooves of the side panels
   (See Fig. 2)

   Ensure that the laminated white surface is facing inwards and the holes are positioned as shown.

3. Attach the top panel (F) to assemble the frame, using screws (T) (See Fig. 3).

   Make sure that the back panel is located properly in the groove in the top panel before tightening the screws.

4. Insert the screw caps (L) over the holes in those frame panels.

5. Fit the straight hinges (N) into the pilot holes of side panels(A&B) to attach the door panels (I&K) with hinge screws (O).
   (See Fig. 4)

Fig. 1





Fig. 2







Fig. 3

Fig. 4



6. Fit the curving hinges (P) into the pilot holes of left internal panel(C) to attach the middle door (J) with hinge screws (O).
   (See Fig. 5)

7. Attach the triangle boards (Q) to the corners of back panel, securing it with glue (not provided) (See Fig. 6)
   Ensure the holes in triangle boards are in line with those in the back panel.

8. Select a suitable location against a wall to fix the cabinet onto the wall using the screws provided. Mark the position for the screw fixings through the four fixing holes in the cabinet back. Drill the fixing holes in the wall and insert the wall plugs (R). Hold the cabinet over the drilled holes and fit the wall screws (S) into the wall plugs through the cabinet back (See Fig. 7.)

9. After wall mounting the cabinet, fit the shelf supports (M) into the holes on each side of cabinet and place the S&L shelf (E1&E2) onto the supports (See Fig. 7).




Fig. 5




Fig. 6




Fig. 7

Care and Maintenance

SAFETY

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

CLEANING

As with all surfaces clean with a damp cloth and mild detergent,do not use bleach or abrasive products.

FITTING

From time to time please ensure there are no loose screws on the product.

SAFETY WARNING INFORMATION BS7449 : 1991

Keep these instructions for future use:

Catalogue Number: 833/0332(D)

Manufacture date: _____

Retailer: **Argos**

Retailer address: **489-499 Avebury Boulevard**
Saxon Gate West
Central Milton Keynes
Bucks, MK9 2NW

WARNINGS

*Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.

This unit contains film backed mirror of nominal thickness of 3 mm

*Do not strike the glass with hard or pointed items.

This unit contains safety backed mirrored doors of a nominal thickness of 3 mm, which is not required to be classified to BS6206 Class C.

*When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substance containing abrasive since these substances scratch glass.


*It is essential that the unit to be fixed to a wall using the fixings provided.

If a glass is chipped or broken replace with glass of the type described on this label. Consult the manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch number or date of manufacture.

A Guide to
Wall Mounting & Fixings

IMPORTANT:

When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.




HINTS:

1) General Rule ⚠ Always use a larger screw and wall plug if you are not sure.
2) Ensure you use the recommended drill bit to match the wall plug and hole size.
3) Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4) Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure the plug is fitting below the ceramic tile to avoid splitting or cracking.
5) Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types Of Walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone, wood or plaster board.

No.1 "Standard" Wall Plug
General Wall Materials



These come in various sizes and are made from plastic or sometimes wood fiber.


No.2 "General Purpose" Wall Plug
Aerated / Breeze Block



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case.
For light loads, a General Purpose Plug can be used.


A Guide to
Wall Mounting & Fixings

No.3 "Shield Anchor" Wall Plug
Heavy Loads




For use with heavier loads such as TV & HiFi Speakers and Satellite Dishes etc.

No.4 "Cavity Fixing" Wall Plug




For use with plaster board partitions or hollow wooden doors.

No.5 "Cavity Fixing - Heavy Duty" Wall Plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets, coat racks.

No.6 "Hammer Fixing" Wall Plug



For use with walls stuck with plaster board. The hammer fixing allows it to be fixed to the wall rather than the plaster board. Always check the fixing is secure to the retaining wall.

CARE & MAINTENANCE

⚠ **SAFETY**

Always check the fitting and location to ensure your safety in and around the home.


⚠ **FITTING**

From time to time check the fitting to ensure the wall plugs or screws do not become loose.

Mirrored Cabinet

Assembly Instructions- please keep for future reference

833/0332



Dimensions

Width - 80cm
Depth - 15.5cm
Height - 64cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 1 - 15/04/10

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 1 and 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




1 Side x 2
(64(h)cm x 13.7(d)cm)




2 Left middle x 1
(59(h)cm x 12.5(d)cm)




3 Right middle x 1
(59(h)cm x 12.5(d)cm)




4 Top / bottom x 2
(77(w)cm x 13.7(d)cm)




5 Back x 1
(60(h)cm x 78(w)cm)




6 Outer door x 2
(64(h)cm x 22.7(w)cm)



7 Middle door x 1
(64(h)cm x 33.8(w)cm)



8 Small shelf x 4
(20.5(w)cm x 12.2(d)cm)











9 Large shelf x 2
(32.5(w)cm x 12.2(d)cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Screw cover x 16	**B**  40mm Screw x 16	**C**  Spring hinge x 4	**D**  Hinge screw x 36
E  Curved spring hinge x 2	**F**  Shelf bracket x 24	**G**  Corner bracket x 4	**H**  Rawl plug x 4
I  40mm Wall screw x 4	**J**  Washer x 2		

Tools required




Phillips screwdriver (medium & large)



Drill

Ruler – Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Connect the 2 x side [1], the left middle [2] and the right middle [3] to 1 x top/bottom [4] using 8 x 40mm screw Ⓑ as shown.


Insert a screw cover Ⓐ over the head of each screw.

Note: ensure the slots of the side panels [1] both point toward the rear of the unit.



Step 2

Slot back [5] into place as shown.




Step 3

Connect 1 x top/bottom [4] to the exposed ends of 2 x side [1], the left middle [2] and the right middle [3] using 8 x 40mm screw Ⓑ as shown.

Insert a screw cover Ⓐ over the head of each screw.

Insert 24 x shelf bracket Ⓕ as shown.



Assembly Instructions

Step 4

Connect 2 x outer door 6 to the side panels using 4 x spring hinge C and 16 x hinge screw D as shown.


Hinge adjustment:

a: To adjust doors up or down, loosen screws shown and move doors to suit.

Once doors are aligned, re-tighten and insert remaining screws D into all hinge plates.

b: To move doors in or out, loosen screws shown and move doors to suit.


Retighten screws.



Step 5


Connect middle door 7 to right middle panel using 2 x curved spring hinge E and 8 x hinge screw D as shown.

See Step 4 for hinge adjustment.



Step 6


Place the small shelves 8 and the large shelves 9 onto the shelf brackets.



Assembly Instructions

Step 7

Position 4 x corner bracket **G** to the rear of the unit as shown to allow wall mounting.




Step 8

The unit can be mounted onto a wall by fixing through the back panel using 2 x 40mm screw **I**, 2 x washer **J** and 2 x rawl plugs **H**.

Note: see the back cover for more information on wall mounting and the suitable use of the supplied rawl plugs.

Warning:
The unit is heavy.
Lift with care.

Warning:
Before drilling, check wall for hidden pipes and cables.



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 “General Purpose” wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 “Cavity Fixing” wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 “Hammer Fixing” wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 “Plasterboard” wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 “Cavity Fixing – Heavy Duty” wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 “Shield Anchor” wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance


Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Triple Mirrored Cabinet

Assembly Instructions – Please keep for future reference | 833/0332



Dimensions

Width - 80cm
Depth - 15.5cm
Height - 64cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Issue 2 - 8/20/12

Safety and care advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels, this could cause damage.

• Assemble the unit as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• ***Note:*** Only apply the glue once you are sure of the assembly.

• The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.

• Parts of the assembly will be easier with 2 people.

• If using power tools, please follow the safety instructions supplied with the tools.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• ***Warning:*** Before drilling, check the wall for hidden pipes and cables.

• Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the Customer Helpline:08456 400800


Please check you have all the panels listed below




1 Top & Bottom Panel x 2




2 Left & Right Side Panel x 2




3 Internal panel x 2




4 Left & Right Back Panel x 2




5 Middle Back Panel x 1




6 Left & Right Adjustable Shelf x 4



7 Middle Adjustable Shelf x 2



8 Left & Right Door x 2








9 Middle Door x 1


Components - Fittings


Please check you have all the fittings listed below

Note:The quantities below are the correct amount to complete the assembly .In some cases more fittings may be supplied than are required.


A  35mm Screw x 16	B  Straight Hinge x 6	C  12mm Screw x 24
D  Screw Cap x 16	E  Plastic Support x 24	F  45mm Screw x 4
G  Wall plug(for solid walls only) x 4		

Tools required


Phillips screwdriver (medium & large)



Flatblade screwdriver (medium)

7mm Suitable drill bit (for use with wall plug)



Drill


Small hammer


Ruler/tape measure


Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1


Assembling straight hinge

a:Loosen straight hinge screw B3 till it can be moved to large hole on the right as shown.

Separate straight hinge B into two parts B1 with screw B3 & B2 with screw B4 .


a:






b:Use 12mm screw C to attach straight hinge B1 & B3 onto internal panels 3


Repeat same step to fix straight hinge B1 & B3 to left&right side panels 2






c:Use 12mm screw C to fix straight hinge B2 & B4 onto mirror door panels 8 & 9

b:



c:



Assembly Instructions

Step 2


Assembling internal panels,top panel and back panel

NOTE:It would be useful to ask someone to help you at this stage.

a:Use 35mm screws Ⓐ to fix internal panels 3 to bottom panel 1

Pls make sure the grooves on internal panels & bottom panel are aligned.

a:




b:Carefully slide middle back panel 5 into grooves of the unit.

Use 35mm screws Ⓐ to fix top panel 1 to the unit.

Note:Please do not tighten screws Ⓐ to maximum as this would ease the following assembling of left & right back panel .

b:



Assembly Instructions

Step 3


Assembling back panel and side panel

NOTE:It would be useful to ask someone to help you at this stage.

Carefully slide left & right back panels 4 into grooves of the unit.

Use 35mm screws A to fix left & right side panels 2 to the unit.

Tighten screws A in top panel to secure the unit



Step 4

Assembling doors

NOTE:It would be useful to ask someone to help you at this stage.

Pls lay the unit flat on the floor to ease assembly.


a :Attach left & right mirror door 8 to the unit by slotting hinges B2 onto B1 , adjust B1 to move hinge screw B3 to the right as shown , tighten it to lock the door panel.

Close the door and make sure the rim of door panel is even with side panels ,this would ease the following assembling of middle door

See "Hinge adjustment" in next step 5-b if the doors need adjusting.

Continued on next page.

a:



Assembly Instructions

Step 4 - continued


Assembling door

NOTE:It would be useful to ask someone to help you at this stage.

b: Repeat step a to fix middle door to the unit .

See "Hinge adjustment" in next step if the doors need adjusting.
It is better to adjust hinge to make the gap between doors within 3mm.

b:




Step 5


Hinge adjustment

a: To move doors up or down

Loosen screws C as shown to move doors up or down to proper position, re-tighten screws C to secure the unit.

a:







b:To move doors left or right
If the gap between doors is too large, pls loosen hinge screws B3 firstly and tighten hinge screws B4 to narrow the gap properly.
Repeat same step until the gap is 2-3mm .

If the gap is too small ,pls loosen hinge screws B4 firstly and tighten hinge screws B3 to enlarge the gap properly.
Repeat same step until the gap is 2-3mm .


b:






c: To move doors in or out
Loosen hinge screws B3 to move doors in or out to proper position, re-tighten screws C to secure the unit.

c:





Assembly Instructions

Step 6


Fixing to the wall

NOTE:It would be useful to ask someone to help you at this stage.


a:Insert screw caps Ⓓ over the screw holes on the outside.

b:Use 45mm screws Ⓕ and wall plugs Ⓖ to fix the unit on the wall.

a:



b:



Step 7

Assembling adjustable shelves


NOTE:It would be useful to ask someone to help you at this stage.

Insert plastic supports Ⓔ into side panels 2 & internal panels 3

Carefully put the adjustable shelves 6 & 7 on it.

NOTE: Please make sure the unit is secure before use.

The assembly is now complete.



NOTE:If you have damaged or missing components, call the Customer Helpline:08456 400800
Argos LTD,489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.