
Mirror 30x48cm With White Wood Shelf

Assembly Instructions – Please keep for future reference | 833/5265



Dimensions

Width - 30 cm
Depth - 10 cm
Height - 48 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Safety and care advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels, this could cause damage.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• ***Note:*** Only apply the glue once you are sure of the assembly.

• The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.

• Assemble the unit as close to its final position (in the same room) as possible.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• ***Warning:*** Before drilling, check the wall for hidden pipes and cables.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

Please check you have all the panels listed below



1 Mirror





2 Shelf

Components - Fittings


If you have damaged or missing components, call the Customer Helpline:08456 400800

Please check you have all the panels listed below

Note:The quantities below are the correct amount to complete the assembly .In some cases more fittings may be supplied than are required.


A 	B 	C 
35mm Screw x 5	Wooden dowel x 2	Wall plug(for solid walls only) x 2

Tools required




Phillips screwdriver (medium & large)

7mm Suitable drill bit (for use with wall plug)



Eye protection (when using a hammer or glue)



Drill




Small hammer



Ruler/tape measure

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Assembling mirror and shelf

NOTE:It would be useful to ask someone to help you at this stage.

Insert wooden dowels (B) into shelf [2]

Use 35mm screws (A) to fix the shelf [2] onto mirror [1]



Step 2

Fixing to wall

NOTE:It would be useful to ask someone to help you at this stage.

a:Drilling two holes in the wall. The distance between two holes is the same as it.


b:Insert wall plugs (C) to the drilled holes with hammer.
Ensure wall plugs are well fitted and are a tight fit in the drilled hole.
Locking 35mm screw (A) into wall plugs (C)

c:Hanging the unit onto the screws


NOTE: Please make sure the unit is secure before use

The assembly is now complete


a:



b:



c:



NOTE:If you have damaged or missing components, call the Customer Helpline:08456 400800
Home Retail Group,489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: ⚠ Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

⚠ Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.

SAFETY WARNING INFORMATION

Keep these instructions for future use:

WARNINGS

*Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.

*Do not strike the glass with hard or pointed items.

* Do not sit or stand upon horizontal glass surfaces.
*When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary do not use washing powders or any other substance containing abrasive since these substances scratch glass.
*It is essentail that this unit is fixed to a wall with the fixings provided.

BS7449 : 1991

Catalogue Number: 833/5265(D)

Manufacture date: July. 15th. 2011

Retailer: **Argos**

Retailer address: **489-499 Avebury Boulevard**
Saxon Gate West
Central Milton Keynes
Bucks, MK9 2NW

This unit contains tempered glass of a nominal thickness of 3 mm, which is not required to be classified to BS6206 Class C.

If a glass is chipped or broken replace with glass of the type described on this label. Consult the manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch number or date of manufacture.