
Wood Bar Plate Rack

Simple Assembly Instructions - **Please keep for future reference**




Components


Ⓐ 1 x Back Panel




Ⓑ 1 x Top Shelf



Ⓒ 1 x Bottom Shelf



Ⓓ 2 x Decoration Wire



Fittings

Ⓐ 8 x Screw



Ⓑ 2 x Wall Plug



Ⓒ 2 x Screw



Ⓓ 6 x Screw



9-04

IMPORTANT

1. *Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.*
2. *Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.*
3. *Take all the fittings out of the plastic bag and separate them into their groups.*
4. *Ensure you have enough space to lay out all the parts before assembly.*
5. *To avoid scratching it is recommended that you assemble the unit on a soft level surface.*

Assembly Instructions

Stage 1 – Fitting the Unit

1. Use Screws Ⓐ to fix the Bottom Shelf Ⓒ onto the Back Panel Ⓐ. **See fig. 1.**




fig. 1

2. Use Screws Ⓐ to fix the Top Shelf Ⓑ onto the Back Panel Ⓐ. **See fig. 2.**




fig. 2

3. Use Screws Ⓓ to fix the Decoration Wires Ⓓ onto the unit. **See fig. 3.**




fig. 3

Assembly Instructions


Stage 2 – Wall Mounting

IMPORTANT: When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs supplied are suitable for supporting the unit. Consult a qualified tradesperson if you are not sure.

NOTE: It would be useful to ask someone to help you at this stage.

WALL MOUNTING: Hold the unit against the wall in the desired location and check if it is horizontal. Mark the wall to indicate where to drill the holes. See fig. 4.

1. Use the Wall Plugs Ⓑ to fit to the holes. Then screw in the Screws Ⓒ through the unit into the Wall Plugs. **See fig. 4 and 5.**


fig. 4




fig. 5


fig. 6

Care and Maintenance

Safety
To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning
As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting
From time to time please ensure there are no loose screws on the product.