



Step 1: Hold the opening of the garbage bag through the bag clip feature.



Step 2: Open the plastic mid-frame and fold the opening of the garbage bag around the plastic mid-frame.



Step 3: Replace the garbage bag by lifting up the bag clip feature.



Step 4: Remove the bag clip feature to pull out the garbage bag.