

The Argos logo consists of the word "Argos" in a white, italicized, sans-serif font, positioned above a white, upward-curving arc that resembles a smile. This logo is set against a black square background.


Argos

**VALUE
RANGE**

**Electronic
kitchen scale**

1

Insert the enclosed lithium battery in the battery compartment at the back of the scale.



Make sure that the positive + side is placed upwards

2

Place the scale on a hard, even surface.



3

To start, touch the **ON/TARE** button.



4

HELLO will show in the display and then **0g**. The scale is now ready to use.

5

Choose the unit of measurement - Kg or Lb. Press the **UNIT** button.



Kg/g




Lb/oz



6

Place the item to be weighed on the platform.




Weight

7


Using the TARE button

Start the scale and when **0g** shows in the display place the first item on the platform.




8

Touch the **ON/TARE** button and the display returns to **0g** shows **Tare**.




9

Add the new item and the weight shows in the display.




10

You can continue to use the **ON/TARE** button to get the individual weight of further items.



11

Press **ON/TARE** after the last item, remove all from the scale and the total weight will show in the display.



12

You can turn off the scale by pressing and holding the **ON/TARE** button or the scale will turn off automatically after 60 seconds.



The battery is low.
Change to a new battery.



The scale is overloaded.
Remove the weight and start again.



HANDLING & CARE

- The scale is a precision instrument. Avoid knocking or dropping it.
- Do not try to disassemble the scale.
- Clean the surface with a glass cleaner. Never immerse it in water or any liquid.
- Keep the scale away from excessive heat or cold.
- The scale is for domestic use only and is not suitable for professional use.
- The total maximum capacity is 5Kg /11lb.

