
power station XL



Contents

- **Juice®Power Station XL** power bank
- Micro USB cable (for charging)
- Instruction Booklet
- Carry pouch

Overview



How to Check the Battery Level

Shake or tap the **Juice® Power Station XL** to check the remaining battery levels.

Interpretation of the LED Indicator

Charging

● ○ ○ ○ = Up to 25% charge
● ● ○ ○ = Up to 50% charge
● ● ● ○ = Up to 75% charge
● ● ● ● = Fully charged.
You can disconnect from the charger or PC

***Charging Time: Approx 10-11 hours**


Discharging

To check the remaining battery level of your **Juice® Power Station XL** power bank, view how many LED's are lit.

Note: It is normal for the Juice® Power Station XL and your device to get warm during charging and discharging. They may get even warmer if you use your device to play videos or for gaming while charging. The Juice® Power Station XL will enter "sleep mode" after 30 seconds when not in use. Shake once before charging your device.

How to Charge Your Power Station XL

1. Plug the **Juice® Power Station XL** into your computer or USB compatible wall charger with 2A current output (DC 5V/2A) via the included micro USB cable.
2. When the **Juice® Power Station XL** is fully charged, disconnect the USB connector. *Charging time depends on the output power of the charging device.



Charging devices with the Power Station XL

1. Connect your device to the USB output port on the **Juice® Power Station XL** with the Micro USB cable provided or use the original cable that came with your device.
2. Shake the **Juice® Power Station XL** and it will automatically start charging your device
3. When your device is fully charged, disconnect the cable. The **Juice® Power Station XL** will shut down automatically.

In order to charge your device, you will need to have a USB cable compatible with your device.

These come standard with all Apple products as well as most other smart phones, tablets and MP3 players. Plug the Standard USB end into the **Juice® Power Station XL**. Now, use the other end of cable and plug it into the device you wish to charge. Once charged, simply unplug your device and store your **Juice® Power Station XL** until you are ready to charge again.

Note: The maximum total output current of the Power Station XL is 2.4A. Power cannot be discharged to the mobile device requiring amperage of more than 2.4A.

Note: Different device manufacturers have different requirements to charge their products, they may also use different cables to charge their devices. These manufacturers may vary the specifications of how to charge a device and they may also introduce other charging methods on their new products, therefore we can not guarantee that the Juice®Power Station XL will be able to charge all devices. Juice® always suggests that you use the original charging cable included with your device to charge your devices.

Lets get techy

Input	Micro USB (DC5V/2A Max)
Output	USB (DC5V/2.4A)
Dimensions	147 x 73.5 x 22.5 mm
Net Weight	362 grams
Capacity	16,800 mAh (Li-ion Battery)

Safety Information

Read all information and warnings before using the **Juice® Power Station XL** power bank.

Improper use of this product may lead to the product being damaged and you (the buyer, not the dealer) will be held responsible for damages such as over heating, the release of toxic fumes, fire or explosion.

- Do not attempt to charge the **Juice® Power Station XL** by using any other method other than a USB charger or computer.
- Do not dismantle or modify the **Juice® Power Station XL** power bank in any way.
- Do not use this power bank in bathrooms etc.
- Do not expose the **Juice® Power Station XL** to moisture or immerse it in liquid. Keep this product dry at all times.
- Do not keep the **Juice® Power Station XL** in an environment that has excessively high temperatures, including intense sunshine.
- Do not throw this product into a fire or leave in a hot environment. Avoid dropping or any other impact or friction to this product.
- Do not place the **Juice® Power Station XL** power bank on flammable materials, such as bedding or carpets during charging.
- Do not touch the **Juice® Power Station XL** with wet hands.
- Disconnect the USB connector from the **Juice® Power Station XL** once you have charged your device.
- Only use this product within the following temperatures: 0˚ to 40˚
- Do not connect input and output in reverse.
- Do not charge the **Juice® Power Station XL** in excess of the rating suggested.
- If any issue arises when using the **Juice® Power Station XL**, disconnect the USB connector from the computer port and contact your dealer.
- In the unlikely event that any liquid from the inside of this product gets into your eyes, do not rub your eyes. Wash your eyes immediately with clean water and consult a physician.
- All Juice® power banks have been tested comprehensively to ensure quality. If you encounter any unusual heat, discolouration or product distortion during charging or storage, please stop using it immediately and contact the dealer. These issues may cause leakage, heat, smoke or ignition of the **Juice® Power Station XL**.
- The **Juice® Power Station XL** is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities (or lack of experience and knowledge) unless they have been given supervision or instructions concerning the use of the **Juice® Power Station XL** by a person responsible for their safety. Children should be supervised to ensure that they do not play with it, this is not a toy.

Legal Liability

The **Juice® Power Station XL** power bank can only be used with compatible products. Please read your equipments compatibility instructions to determine whether this **Juice® Power Station XL** matches your equipment requirements. The manufacturer will not be liable for any damage to your electronic equipment during the use of this product. Gusto will not be held responsible for any equipment or accessories not suitable for use with the **Juice® Power Station XL**. The manufacturer will not be held liable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of the **Juice® Power Station XL**.

Activate your free **1 year** warranty at juice.co.uk

Designed in the UK. Product made in China. Please retain proof of purchase as this will form part of your warranty. If you do not have proof of purchase for the product the warranty will be void Design & specification may be subject to change without prior notice.
Juice® Power Station XL is part of the ©Juice® brand.

juice.co.uk
customerservices@juice.co.uk
Juice®. 10 Haslemere Way. OX16 5RW. UK

WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

RoHS