

juice® wireless weekender




all the wireless power you will need for a weekend

Contents

- Juice® Wireless Weekender powerbank
- Micro USB to USB cable (for charging)
- Instruction booklet

Overview



Specifications

- **Input -** Micro USB : DC5V/2A
Type C : DC5V/3A DC9V/2A DC12V/1.5A PD:18W
- **Output -** USB A : DC5V/3A DC9V/2A DC12V/1.5A QC18W
TYPE-C : DC5V/3A DC9V/2A DC12V/1.5A PD:18W
WIRELESS : DC5V/1A 5W
- **Charge Time** 8-9 hours
- **Battery Capacity** 10,000mAh
- **Standby** Polymer Lithium-ion battery
- **Cycle Life** Around 6 months
- **Dimensions** Around 500 charges
- **Net Weight** 152 x 78 x 18.5mm
- **Net Weight** 268g

Interpretation of the LED's

- 1 Blue Less than 25% charge remains
- 2 Blue 25 to 50% charge remaining
- 3 Blue 50 to 75% charge remaining
- 4 Blue 75 to 100% charge remaining

How to charge the Wireless Weekender

1. Plug the Juice® Wireless Weekender into your computer or a USB compatible mains charger with a current output of up to 3A (DC 5V,2,000mA) using the included micro USB cable.
2. The LED's will indicate when the Wireless Weekender powerbank is charging. The first blue LED light will turn on when the power bank is at least 25% charged and will remain on whilst charging. When the power bank is 50% charged two LED's will turn on, and so on.
3. When all four blue LED lights show and remain on, the powerbank is fully charged. Now you can disconnect from the computer or charger. The power bank's LED's will power off when idle to conserve energy.
4. In order to charge your device, you will need a USB cable compatible with your device. These come included as standard when purchasing most devices. Plug the device's standard USB end in to the Juice® Wireless Weekender. Plug the other end of the cable into the device you wish to charge. Once charged, simply unplug your device and store your Juice® Wireless Weekender until you are ready to use it again.

***Charging time of around 8-9 hours. This will depend on the output power of the charger.**

NOTE: It is normal for the Juice® Wireless Weekender and your device to get warm during charging and discharging. It may get even warmer if you use your device to, for example, play video or game while charging.

Wireless charging

1. Place your compatible wireless device on the centre of the centre of the Juice® Wireless Weekender on the side with the LED indicator lights.
2. Press the power button to turn the Juice® Wireless Weekender on, now you can charge.
3. When your device is fully charged or you want to stop charging, remove your device. N.B - The Juice® Wireless Weekender will shut down automatically after being idle for 1 minute.

Charging with a cable

1. Connect your device to the USB port on the Juice® Wireless Weekender with the provided Micro USB cable. For Apple devices you will need to use your original cable that was supplied with your device.
2. Press the power button to turn the Juice® Wireless Weekender on, now you can charge.
3. When your device is fully charged or you want to stop charging, disconnect the cable.

NOTE: Mobile and gadget device manufacturers have different requirements to charge their products, they may also use different cables to charge their devices. These manufacturers may vary the specifications of how to charge a device and they may also introduce other charging methods on their new products, therefore we can not guarantee that the Juice® Wireless Weekender will be able to charge all devices. Juice® always suggests that you use the original charging cable included with your device to charge your devices.

Safety information

Read all information and warnings before the use of this product. Improper use of this product may lead to product damage. You (the buyer) other than the dealer will be held liable for damages such as overheating, toxic fume, fire or explosion.

- Do not attempt to charge the power bank

by any other method other than with USB equipment or a computer.

- Do not modify or disassemble the battery.
- Do not dismantle or refit this power bank in anyway.
- Do not use this power bank in bathrooms.
- Do not expose the battery to moisture or immerse it in liquid. Keep it dry at all times.
- Do not keep the power bank in an environment with excessively high temperatures, including intense sunshine.
- Do not throw the power bank into a fire or place in extremely hot environments.
- Avoid dropping, fierce bumping, friction or any other direct impact to the power bank.
- Do not place the power bank on flammable materials (beds or carpets) during charging.
- Do not touch the power bank with wet hands.
- Disconnect the USB connector from the power bank after charging.
- Only use the power bank in temperatures ranging from 0° to 40°.
- Do not connect input and output in reverse.
- Do not charge the power bank in excess of the rating.
- Do not subject the power bank to strong impact and do not throw it.
- In case of any abnormalities or problems, disconnect the USB connector from the computer port and contact your dealer.
- If any liquid from the inside of this product gets into your eyes, do not rub your eyes, but wash them with clean water and immediately consult a doctor.
- All batteries have been tested comprehensively to ensure quality. If heat, discolouration or transformation are found during charging or storage please stop using immediately and contact the dealer. Neglect of doing so may cause the power bank to leak, overheat, smoke or ignite.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities. Or by anyone with lack of experience and knowledge, they should only use this product if they are under supervision or have been instructed on how to use the power bank by a person responsible for their safety. Children should be supervised

to ensure that they do not play with the power bank, it is not a toy.

Legal liability

This Juice® Wireless Weekender can be used only with compatible electronic equipment. Please read your devices packaging and instruction manuals to determine whether this Juice® Wireless Weekender is compatible with your equipment. The manufacturer shall not be held responsible for any damage to any electronic equipment during the use of this product. The manufacturer shall not be held liable for any damage caused by misuse or any damage incurred by the buyer or the third party rising from any intentional or unintentional use of the Juice® Wireless Weekender, this also includes any equipment or accessories used with this product. As mentioned above, the manufacturer shall not be held liable for damage caused by misuse of the Juice® Wireless Weekender.

Activate your free 1 year warranty at juice.co.uk

Designed in the UK. Product made in China. Design & specification may be subject to change without prior notice. ©Juice. Please retain proof of purchase as this will form part of your warranty, if you do not have proof of purchase for the product the warranty will be void. If you have purchased the product from a retailer please return the product directly to the retailer. If you have purchased the product from juice.co.uk please contact our customer service team. Juice® Wireless Weekender is part of the Juice® brand. ©Gusto Telecom Solutions

juice.co.uk customerservices@juice.co.uk
©Gusto Telecom Solutions. Juice®
10 Haslemere Way. OX16 5RW. UK



WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.