



- The build-up of dirt inside your Vype ePen top and the top of your battery unit may prevent you from enjoying your experience and it may disrupt normal charging. To prevent this, check and if necessary detach your ePen top from the ePen battery, clean with a dry cloth and carefully blow into the ePen top to dislodge any build-up of dirt.
- The USB charging cable will automatically stop charging your ePen battery after a period of 3 hours. It has an overvoltage, an overcurrent and a short-circuit protection function.
- The battery controller has a short-circuit protection function: during inhalation, if the battery short circuits, the light on the button will flash red 3 times and the battery will shut down.
- Your ePen device is only suitable for operation between 0-40°C. If your device is operated outside of this temperature range it may be damaged or stop working.
- Keep Vype products dry. Precipitation, humidity or moisture can corrode electronic circuits.
- The recommended storage temperature for Vype products is between 0-25°C.
- If either the ▲ or ▼ button is pressed for more than 8 seconds, the light on the device will flash and the ePen will shut down. To restart the ePen, follow the 'How to use your ePen' instructions.
- Protection provided by the equipment may be impaired if used in a manner not specified by the manufacturer.
- Do not use e-cigarettes when you, or anyone in the vicinity, is using oxygen.
- If you have any queries or doubts about the use of your ePen or any other Vype products, please contact the Vype Customer Care Team.

Disposal and recycling of Vype products

Electrical and electronic goods and batteries should not be disposed of as part of regular household waste, but should be separately collected for recovery and recycling. We are committed to minimising our impact on the environment – please see our website, govype.com, for more information on how to dispose of your Vype products and details of our recycling programme and how to return used products to us.

THIS PRODUCT CONTAINS NICOTINE WHICH IS A HIGHLY ADDICTIVE SUBSTANCE*. NOT RECOMMENDED FOR NON-SMOKERS. THIS PRODUCT MAY BE HAZARDOUS TO HEALTH.

*except zero nicotine products.

KEEP OUT OF REACH OF CHILDREN. KEEP OUT OF REACH OF ANIMALS. IF SWALLOWED: Rinse mouth. **IF ON SKIN:** Wash with plenty of soap and water. Call a **POISON CENTRE** or doctor/physician if you feel unwell.

THIS PRODUCT IS NOT SUITABLE FOR USE BY:

- Persons under the age of 18.
- Persons who are allergic/sensitive to nicotine.
- Pregnant or breast-feeding women.
- Persons who should avoid using tobacco or nicotine products for medical reasons.
- Persons with an unstable heart condition, severe hypertension or diabetes.

IMPORTANT SAFETY INFORMATION:

Immediately stop use of this product and seek medical advice if you experience any of the following: Development of an irregular heartbeat; allergic reaction such as rash, itching or swelling of the tongue, mouth or throat; feeling faint; nausea; headache; or any other unusual or adverse effect.

Distributed by British American Tobacco UK Limited, One Eton Street, Richmond upon Thames, London, TW9 1EF, UK
Vype Customer Care: Phone: +44 (0)800 1337 350



eLiquid made in the UK. Vype ePen device, USB charging cable and cartridge (excluding eLiquid) made in China.



Model number: ep2

WY_UK_EPEN_STK_LF01

ePen kit User Guide



Quick Start:



Step one:
Open your Vype ePen device by simply pulling the mouthpiece from the battery.



Step two:
Screw the ePen flavour cartridge onto the battery. Replace the mouthpiece by pushing down and clicking back onto the battery.



Step three:
Click on either button three times to switch on your Vype ePen. That's it! Simply press down on one of the two power settings whilst inhaling to enjoy rich vapour at the click of a button. Enjoy!



Know your Vype ePen



Tips:



- Each ePen cartridge is designed for single use. You should not attempt to refill as this may lead to leakage and damage your device.
- All Vype eLiquids have been developed bespoke to Vype devices for an optimal vaping experience.

How to use your ePen

- For optimal performance, your ePen should be fully charged before first use.
- Open the device by detaching the ePen top from the ePen battery.
- Remove the silicone cover on the ePen



cartridge before screwing it onto the ePen battery. Be careful not to over-tighten.



- Once the ePen cartridge is securely attached to the ePen battery, place the ePen top back over the ePen cartridge and push gently to secure.

- To switch on your ePen, rapidly click the double arrow button  or single arrow button  three times.

- To begin your vaping experience, press one of the two buttons and hold it down whilst inhaling.

- The ePen is equipped with two voltage

settings. Press and hold the double arrow button  for more vapour, press and hold the single arrow button  for less vapour.

- If you press both buttons at the same time, your ePen will not work.
- Only use Vype ePen cartridges with the Vype ePen device.
- The ePen can be locked by rapidly clicking on the double arrow button  or single arrow button  three times. The ePen will confirm that it has switched off by flashing the LED three times.
- If the ePen remains unused for 10 minutes, it will

automatically switch off and will need to be switched back on to use.

- To confirm whether your ePen is on or off, press either of the buttons once. If the ePen is on, the LED will illuminate for three seconds. If the ePen is off the LED will not illuminate.

When to change your ePen cartridge

It's time to change your ePen cartridge when:

- Your ePen stops producing vapour.
- You notice a deterioration in the taste or quality of the vapour.

If your ePen stops producing vapour and the cartridge is not yet empty, check your battery is fully charged.

Battery charging indicators on your Vype ePen

When the ePen is turned on or off, when either button is pressed once when the ePen is on, or when the ePen is charging, the colour of the LED will indicate the battery level.

- **Green:** Your battery is between 50% and 100% charged.
- **Amber:** Your battery is between 20% and 50% charged.
- **Red:** Your battery is less than 20% charged.

Your ePen battery may run out of charge before the ePen cartridge is finished so don't automatically discard the cartridge when charging the battery as there may be eLiquid in it.

How to charge your Vype ePen

- To charge your ePen, attach the USB charging cable supplied with your ePen kit to the micro USB port on the base of the ePen.
- Connect the other end of the USB charging cable to the USB port of a computer.
- When charging, the LED on the ePen will pulsate. The colour of the LED will indicate

the current battery charge level.

- When the LED shows continuous green, the ePen is fully charged and the USB charging cable should be disconnected.
- It should take no longer than 2 hours to fully charge your ePen battery.
- If your ePen LED starts to flash red rapidly whilst charging please disconnect and contact the customer care line.
- You can also charge your ePen using a Vype USB car charger or Vype wall plug which are available at govype.com.

Important product use information

- To avoid the risk of fire, injury and/or damage to your Vype ePen or other property, only charge your Vype ePen battery with the equipment provided in your Vype ePen kit or with compatible Vype charging accessories (available at govype.com).
- Never leave your battery unattended whilst on charge.
- Never keep loose batteries in your pocket, particularly next to keys or coins.
- Rating input of USB charging cable: DC 4.2 V 500 mA.