


MULTI-PURPOSE TIDY RAIL

CONTENTS


A. END SECTION x 2




B. SHELF SUPPORT x 6




D. BASE x 1



C. UPRIGHT SUPPORT x 1



E. SHELF x 3



F. SPACER x 2




G. CROSSBAR x 1




H. SCREW x 20




J. THREADED END-CAP x 4




K. WHEEL x 4



L. ALLEN KEY x 1



M. SPANNER x 1



ASSEMBLY INSTRUCTIONS

1. Assemble shelf supports to end section (Dia. 1)

Secure six shelf supports (B) to end section (A) using screws (H) and tighten with allen key (L).

2. Assemble upright support to shelf supports (Dia. 1)

Fit upright support (C) to shelf supports (B) using six screws (H).

3. Assemble base to end section and upright support (Dia. 1)

Assemble base (D) to end section (A) using two screws (H). Attach base to upright support (C) placing flat surface of spacer onto end of upright support then insert screw through hole in base and spacer (F) and screw into upright support using allen key (L).

4. Assemble crossbar to upright support (Dia. 2)

Fix crossbar (G) to upright support (C) using screw (H).

5. Assemble end section to base and crossbar (Dia. 2)

Using three screws (H) attach end section to base (D) and crossbar (G).

6. Fit shelves to shelf supports (Dia. 2)


Position shelf (E) over two shelf supports (B) and push down gently until shelf clips into place on both sides. Repeat for other two shelves.

7. Attach threaded end-caps and wheels (Dia. 3)

Insert threaded end-cap (J) into end sections. Ensure screw thread of end cap correctly aligns with hole for wheel in end section, then screw wheel (K) into position and tighten firmly with spanner (M) provided.

8. Final tightening of screws and nuts.


To ensure stability, use allen key (L) and spanner (M) provided to tighten all screw and nut assemblies.



Multi-Purpose Tidy Rail

Assembly Instructions - Please keep for future reference

875/0352



Dimensions

Width - 106cm

Depth - 43.5cm

Height - 166cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.
- Assemble the unit as close to its final position (in the same room) as possible.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the panels listed below


- 1** End section x 1




- 2** Upright section x 1




- 3** End section x 1




- 4** Base x 1




- 5** Crossbar x 1 (73cm)



- 6** Shelf support x 6 (28cm)









- 7** Shelf x 3



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


<p>A </p> <p>38mm Screw x 20</p>	<p>B </p> <p>Spacer x 2</p>	<p>C </p> <p>Threaded cap x 4</p>
<p>D </p> <p>Castor x 4</p>	<p>E </p> <p>Allen key x 1</p>	<p>F </p> <p>Spanner x 1</p>

Assembly Instructions


Step 1

Note: It would be useful to ask someone to help you at this stage.

a: Insert Threaded end cap **C** into End sections **1** & **3**. Ensure screw of End cap **C** correctly aligns with hole for castor **D** in End section **1** & **3**, then screw Castor **D** into position and tighten firmly with Spanner **F**.



b: Secure Shelf supports **6** to End section **1** using Screws **A** and tighten with Allen key **E**. And then fit Upright support **2** to Shelf supports **6** using Screws **A**.




Assembly Instructions


Step 2

Finishing the Unit

a: Attach Base **4** to End section **1** using Screws **A**, and then attach to Upright support **2** as shown at the figure.



b: Fix Crossbar **5** to Upright support **2** and End section **3** using Screws **A**. Then using Screws **A** attach End section **3** to Base **4** and Crossbar **5**.




Assembly Instructions

Step 3

Finishing the Unit

a: Stand product up. Position Shelf **7** over two Shelf support **6** and push down gently until shelf **7** clips into place on both sides.

a:



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**