
Assembly Instructions


Step 3


Slide the canvas shoe holder **D** onto the support tubes as shown.



Step 4

Connect the second set of legs to the other ends of the support tubes as shown, using 4 x screw **E** and 4 x washer **F**.






Step 5

Connect the Velcro strap underneath the bottom support rails to secure the canvas shelf.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0121 753 7720**

Shoe Storage Unit

Assembly Instructions- please keep for future reference | 875/3751



Dimensions

Width - 46cm
Depth - 35cm
Height - 131cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0121 753 7720**

Issue 1 - 01/12/09

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed below and on page 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components

If you have damaged or missing components, call the **Customer Helpline: 0121 753 7720**


Please check you have all the panels listed below



A Top tube x 2
(73.2(w)cm)

B Base tube x 4
(65.7(w)cm)

C Support tube x 4
(42.4(w)cm)



D Canvas show holder x 1
(40.5(w)cm x 120(h)cm x 30.8(d)cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0121 753 7720**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


E  Screw x 8	**F**  Washer x 8

Tools required



Crosshead screwdriver

Ruler – Use this ruler to help correctly identify the screws and parts




Assembly Instructions

Step 1

Connect 1 x top tube **A** to 2 x base tube **B** as shown to form a leg of the unit.

Repeat for the other top tube and base tubes to form the other leg.



Step 2

Connect the four support tubes **C** to one of the legs as shown, using 4 x screw **E** and 4 x washer **F**.

