We hope you have many years enjoyment with your purchase.

ASSEMBLY INSTRUCTIONS INSIDE

IMPORTANT

Please keep these instructions in a safe place for future use.


PLEASE DO NOT SIT ON THE STEPS. This is not seating furniture.

The unit must be attached to a wall with the angle plate (E) provided.
The assembly of the angle plate must be performed by a competent person.
Since wall materials differ, the screw and wall anchor for fixing the unit to the wall are excluded.
Please contact your local specialised dealer for purchase advice.

FURNITURE

Understair Storage

Easy Assembly Instructions




Before you start, here is some helpful advices.

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
3. Assemble this product on a carpet.
4. All you will need to assemble this unit is a screwdriver and light hammer.
5. Keep glue and fittings out of childrens' reach.

In the unlikely event that this product has missing or damaged parts, please call 0845 640 0800 to obtain spares.

Component parts and fittings contained in the box

Chest = 10 parts



Total 10 parts

Fittings

A Plug x 26




B Locking Screw x 10



C Locking Nut x 10




D Wood screw x 16




E Angle plate x 4




F Wood screw x 5



G Screw cover x 1



ASSEMBLY - STAGE ONE



Step Shelf and Frame

Step 1


. Insert 4 (A) in both ends of ❸ and push one side into the holes in middle ❻ .

. Screw 2 (D) to fasten panel ❸ with Panel ❻.

. Screw 2 (B) into back edge holes of right ❺ ❻ .


. Insert 4 (C) into holes in front face of panel ❸.

. Tighten (C) with a screwdriver.




ASSEMBLY - STAGE TWO

Step Shelf and Frame



Step 2

. Repeat step 1 for panel❺❹.



Step 3

. Insert (A) in both ends of ❷.


. Screw (D) to fasten panel❷ with panel ❻ ❺❹.

. Insert 2 (C) into holes in right face of panel❷.

. Screw 4 (B) into back under face of panel❼.

. Tighten (C) with a screwdriver.

. Screw (D) to fasten panel❶ with panel❷ ❸




Step 4

. Screw (F) to fasten (E) with panel❷❻ ❺❹ .

. Insert a wall anchor into the wall.

. Screw a longer screw through (E) into the wall anchor to fasten (E) with the wall .




Please purchase this screw and wall anchor from your local specialised dealer

The unit must stand on the floor and be attached to a wall

PLEASE DO NOT SIT ON THE STEPS. This is not seating furniture.

Understairs Storage Unit

Assembly Instructions - Please keep for future reference | 875/3775



Dimensions

Width - 81cm

Depth - 23.6cm

Height - 91.2cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Ref. no. 875/3775 Date: 05/10/09

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• ***Note:*** Only apply the glue once you are sure of the assembly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


Please check you have all the panels listed below




1 Top Panel (208 x 235mm)




2 Small Side Panel x 4 (208 x 234mm)




3 Small Shelf Panel (395 x 235mm)




4 Central Panel (595 x 235mm)



5 Large Shelf Panel (795 x 235mm)



6 Bottom Panel (795 x 235mm)








7 Large Side Panel (912 x 236mm)

Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than are required.


A  50mm Screw x 18	**B**  Wooden Dowel x 8	**C**  Locking Pin x 4
D  Locking Nut x 4	**E**  Covering Sticker x 10	**F**  Glue x 1
G  Wall Strap x 1	**H**  14mm Screw x 1	**I**  Wall Plug x 1
J  30mm Screw x 1		


Tools required


Phillips screwdriver (medium & large)



Flatblade screwdriver (medium)


Small hammer


Ruler/tape measure


Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Attaching small shelf panel

a: Place a small amount of Glue (F) into the dowel holes and onto the joint's surfaces.


Use Locking Pin (C) and Wooden Dowels (B) to fix the Small Side Panel [2] onto the Top Panel [1] .


Note: Insert Locking Pin as far as shown.
Do not over tighten.


Use Locking Nut (D) to fix the unit.

Use Screws (A) to fix the Small Shelf Panel [3] onto the Small Side Panel [2] .

a:







Step 2


Attaching central panel


a: Place a small amount of Glue (F) into the dowel holes and onto the joint's surfaces.

Use Locking Pin (C) and Wooden Dowels (B) to fix the Small Side Panel [2] onto the Small Shelf Panel [3] .

Note: Insert Locking Pin as far as shown.
Do not over tighten.

a:






b: Use Locking Nut (D) to fix the unit.

Use Screws (A) to fix the Central Panel [4] onto the Small Side Panel [2] .

b:



Assembly Instructions

Step 3


Attaching large shelf panel

a: Place a small amount of Glue (F) into the dowel holes and onto the joint's surfaces.

Use Locking Pin (C) and Wooden Dowels (B) to fix the Small Side Panel [2] and Central Panel [4] .

Note: Insert Locking Pin as far as shown.
Do not over tighten.


a:



b: Use Locking Nut (D) to fix the unit.

Use Screws (A) to fix the Large Shelf Panel [5] onto the Small Side Panel [2] .

b:



Step 4


Attaching bottom panel

a: Place a small amount of Glue (F) into the dowel holes and onto the joint's surfaces.

Use Locking Pin (C) and Wooden Dowels (B) to fix the Small Side Panel [2] onto the Large Shelf Panel [5] .

Note: Insert Locking Pin as far as shown.
Do not over tighten.

a:




Assembly Instructions

Step 4 - continued

b: Use Locking Nut Ⓓ to fix the unit.

Use Screws Ⓐ to fix the Bottom Panel 6 onto the Small Side Panel 2 .

b:




Step 5

Attaching large side panel

a: Place a small amount of Glue Ⓝ onto the joint's surfaces.


Use Screws Ⓐ to fix the Top Panel 1 and Small Shelf Panel 3 ,Central Panel 4 ,Large Shelf Panel 5 and Bottom Panel 6 onto the Large Side Panel 7 .

a:



b: Use Covering Stickers Ⓔ to cover the screw heads.

b:



Assembly Instructions

Step 6

Fixing to wall

It is recommended that the storage unit is fixed to a wall.

Use Screw (H) to fix the Wall Strap (G) onto the back of the top panel.

With help, move storage unit into position.

Warning:
The storage unit is heavy.
Lift with care.


Mark fixing hole on wall and remove storage unit.

Drill a hole and insert Wall Plug (I).

Warning:
Before drilling, check wall for hidden pipes and and cables.


Reposioion storage unit and fix Wall Strap (G) using Screw (J).

The assembly is now complete.



Note: Wall plug is not supplied.

The correct type of fixing must be used for your wall, seek professional advice if in doubt.



If you need help or have damaged or missing parts, call the
Customer Helpline: 08456 400800

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.


Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.

Understairs Storage Unit

Assembly Instructions - Please keep for future reference | 875/3775



Dimensions

Width - 81cm

Depth - 23.6cm

Height - 91.2cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Version2 Date: 26/11/12

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not use this item if any components are missing or damaged.

• Do not stand on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**


Please check you have all the panels listed below




1 Top panel (20.8 x 23.5cm)




2 Small side panel x 4 (23.4 x 20.8cm)



3 Small shelf panel (39.5 x 23.5cm)




4 Central panel (59.5 x 23.5cm)



5 Large shelf panel (79.5 x 23.5cm)



6 Bottom panel (79.5 x 23.5cm)




7 Large side panel (91.2 x 23.6cm)


Components - Fittings


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than are required.


A  50mm Screw x 18	**B**  30mm Dowel x 8	**C**  39mm Locking pin x 4
D  15mm Locking nut x 4	**E**  Screw cover x 10	**F**  Wall plug x 1
G  Wall strap x 1 (This screw is included in the bag of wall strap)  x 1	**H**  14mm Screw x 1	


Tools required


Phillips screwdriver (medium & large)



Flatblade screwdriver (medium)


Small hammer


Ruler/tape measure


Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Attaching small shelf panel


Use Locking pin C and Dowels B to fix the Small side panel 2 onto the Top panel 1.


Note: Insert Locking pin as far as shown.
Do not over tighten.


Use Locking nut D to fix the unit.


Use a screwdriver to turn Locking nut D clockwise to lock.

Use Screws A to fix the Small shelf panel 3 onto the Small side panel 2.










Step 2


Attaching central panel

a: Use Locking pin C and Dowels B to fix the Small side panel 2 onto the Small shelf panel 3.

Note: Insert Locking pin as far as shown.
Do not over tighten.

a:







b: Use Locking nut D to fix the unit.


Use a screwdriver to turn Locking nut D clockwise to lock.

Use Screws A to fix the Central panel 4 onto the Small side panel 2.

b:







Assembly Instructions


Step 3

Attaching large shelf panel

a: Use Locking pin Ⓒ and Dowels Ⓑ to fix the Small side panel 2 onto the Central panel 4 .

Note: Insert Locking pin as far as shown.
Do not over tighten.

a:




b: Use Locking nut Ⓓ to fix the unit.

Use a screwdriver to turn Locking nut Ⓓ clockwise to lock.

Use Screws Ⓐ to fix the Large shelf panel 5 onto the Small side panel 2 .

b:



Step 4


Attaching bottom panel

a: Use Locking pin Ⓒ and Dowels Ⓑ to fix the Small side panel 2 onto the Large shelf panel 5 .

Note: Insert Locking pin as far as shown.
Do not over tighten.

Continued on next page.

a:



Assembly Instructions


Step 4 - continued

b: Use Locking nut Ⓓ to fix the unit.

Use a screwdriver to turn Locking nut Ⓓ clockwise to lock.

Use Screws Ⓐ to fix the Bottom panel 6 onto the Small side panel 2 .

b:




Step 5

Attaching large side panel


a: Use Screws Ⓐ to fix the Large side panel 7 onto the Top panel 1 ,Small shelf panel 3 ,Central panel 4 , Large shelf panel 5 and Bottom panel 6 .

a:



b: Use Screw covers Ⓔ to cover the screw heads.

b:



Assembly Instructions

Step 6

Fixing to wall

It is recommended that the storage unit is fixed to a wall.

Use Screw (H) to fix the Wall strap (G) onto the back of top panel.

With help, move storage unit into position.

Warning:
The storage unit is heavy.
Lift with care.


Mark fixing hole on wall and remove storage unit.

Drill a hole and insert Wall plug (F).


Warning:
Before drilling, check wall for hidden pipes and cables.


Reposition storage unit and fix wall strap using Screw (G).

Assembly is complete.



Note: Wall plugs supplied are for solid wall only.
The correct type of fixing must be used for your wall, seek professional advice if in doubt





If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.