


Assembly Instructions

Step 1


Slot the four legs **2** in between the rails of shelves **1** as shown.

Note: Make sure the screw holes in the legs line up with the screw holes in the shelves.




Step 2

Insert screw **A** into the screwholes as shown and tighten using a Phillips screwdriver.



Step 3

Inserting the wooden dowels **B** into the holes on the top of each leg allows multiple shoe racks to be securely stacked.




If you need help or have damaged or missing parts, call the Customer Helpline: 0121 753 7720

2-Tier Shoe Rack

Assembly Instructions- please keep for future reference

875/4860



Dimensions

Width - 70cm
Depth - 26cm
Height - 34cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0121 753 7720

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 3 and 4.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.


- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels

Please check you have all the panels listed below



1 Shelf x 2
(70(h)cm x 26(d)cm)



2 Leg x 4
(34(h)cm)

Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 0121 753 7720**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Screw x 8



Wooden dowel x 4

Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws

