
# 6 Double Hooks on a Board

## Assembly Instructions - Please keep for future reference

875/5223

875/5254



### Dimensions

Width - 70cm
Depth - 7cm
Height - 10.5cm

## Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Issue 1 - 30/03/10

# Safety and Care Advice

## **Important** – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 .

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

## Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

# Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

## Please check you have all the panels listed below







1 Board (70x7cm)


# Components - Fittings

## Please check you have all the fittings listed below


***Note:*** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

| | | |
|---|---|---|
| A  Hook x 6 | B  10mm Bolt x 6 | C  38mm Screw x 2 |
| D  Wall plug (for solid walls only) x 2 | | |


## Tools required



Phillips screwdriver (medium)




Drill



Small hammer




6mm Suitable drill bit (for use with wall plug)



Eye protection (when using a hammer or glue)


## **Ruler** - Use this ruler to help correctly identify the screws



# Assembly Instructions

## Step 1

Fix the hooks Ⓐ onto board 1 with bolt Ⓑ.




## Step 2

**Fixing to wall**

It is recommended that the board is fixed to a wall.


Mark fixing hole on wall.

Drill 6mm hole and insert wall plug Ⓓ.

***Warning:***
Before drilling, check wall for hidden pipes and cables.

Insert the wall plug Ⓓ into the drilled holes , and insert wall screw Ⓒ into wall plug Ⓓ. Take the unit onto wall with using the metal hanger of board fit to wall screw Ⓒ.

***Warning:***
The Maximum loading weight is 10kg.




If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

# A Guide to - Wall Mounting & Fixings

## *Important note:*

**If plastic wall plugs are supplied with your product:**



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

***Important:*** **When drilling into walls always check that there are no hidden wires or pipes etc.**

**Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.**

### *Hints:*

**1: General rule:** Always use a larger screw and wall plug if you are not sure.

**2:** Ensure you use the recommended drill bit to match the wall plug and hole size.

**3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


**4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

**5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


**You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.**

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.