Assembly Instructions

Step 2

Insert 2 x 30mm wooden dowel © and 4 x connector B into the rear side of front panel 2 as shown.


Step 3

Connect one of the end panels 3 to front and back panels using 4 x 40mm bolt A as shown.

Note: ensure that the horizontal grooves in the panels are all at the bottom.

Step 4


Slide the base panel 4 into the grooves at the bottom of the back and front panels as shown.



Assembly Instructions

Step 5

Connect the other end panel 3 to front and back panels using 4 x 40mm bolt A as shown.




Step 6

Connect the lid 5 using 2 x hinge 1 and 8 x 14mm screw 1 to fix the hinges into place.

Connect the friction stays **f** to the under side of the lid and the inside of the box using 8 x 14mm screw **f** as shown.

Step 7


Insert a screw cover **G** into each of the screw holes to complete the unit.



If you need help or have damaged or missing parts, call the Customer Helpline: 0121 753 7720

Blanket Box

Assembly Instructions- please keep for future reference



Dimensions

Width - 76cm Depth - 40cm Height - 45cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0121 753 7720



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed opposite.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.


• Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal

Components - Panels


Please check you have all the panels listed below








4 Base panel x 1 (72(w)cm x 36.6(d)cm)





3 End panel x 2

(43.5(h)cm x 39(d)cm)



5 Lid x 1 (76(w)cm x 40(d)cm)

Components - Fittings If you have damaged or missing components, call the Customer Helpline: 0121 753 7720


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.















Tools required



Ruler – Use this ruler to help correctly identify the screws

5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1

Insert 2 x 30mm wooden dowel C and 4 x connector **B** into the back panel 1 as shown.

