
ARGOS Ltd.

KD Sea Grass Chest 875/7276 (D)

Easy Assembly Instructions



Introduction

Tools required:

Allen Key – Supplied.

Care & Use.


- **Dust with a clean cloth / duster.**
- **Do not use water.**
- **Do not allow to become damp.**

Note: Do not tighten any of the screws until all parts are together.

Issue date: 27/03/2007
Revision number: 3


Components / fixings list

Components




A – Rear Panel
B – Front Panel
C – Base board
D – Lid
E – Left hand side
F – Right hand side


Fixings




Screws x 16



Hinge rods x 4




Allen key - supplied



Hooks x 2

Issue date: 27/03/2007
Revision number: 3

ASSEMBLY – STAGE ONE



Front / Base / Sides assembly.


1. Attach part 'A' Back Panel to part 'C' Base using 3 screws.


The screws should only be screwed in 2 or 3 turns until ALL panels are in place. Then fully tighten all the screws.


Note: Poke the sea grass to find the screw hole. The screws go through these holes to secure the panels. See drawing opposite.

2. Attach parts 'E' & 'F' Side Panels to Base / Rear panel assembly using 6 screws.

Ensure that the handles are on the outsides, & that the lid securing chain fixings are near the back panel.









Issue date: 27/03/2007
Revision number: 3

ASSEMBLY – STAGE TWO




Front / Lid assembly

3. Attach part 'B' Front panel to Sides & Base, using 7 screws.




Finally fully tighten all screws.

4. Attach Lid 'D' to chest assembly, by locating the hinge flaps together & then securing by pushing the 'Rods' in from both sides of the hinge.




Issue date: 27/03/2007
Revision number: 3

ASSEMBLY – STAGE THREE



Final lid assembly

5. Attach the chain on the lid & on the rear inside face of each side to the hook as shown.




Issue date: 27/03/2007
Revision number: 3

ARGOS Ltd.

KD Sea Grass Chest 875/7276 (D)

Easy Assembly Instructions



Introduction

Tools required:

Allen Key – Supplied.

Care & Use.


- **Dust with a clean cloth / duster.**
- **Do not use water.**
- **Do not allow to become damp.**

Note: Do not tighten any of the screws until all parts are together.

Issue date: 18/11/2009
Revision number

Components / fixings list

Components



A – Rear Panel
B – Front Panel
C – Base board
D – Lid
E – Left hand side
F – Right hand side

Fixings



Screws x 16



Hinge rods x 2



Allen key - supplied

Issue date: 18/11/2009
Revision number

ASSEMBLY – STAGE ONE





Front / Base / Sides assembly.

1. Attach part 'A' Back Panel to part 'C' Base using 3 screws.

The screws should only be screwed in 2 or 3 turns until ALL panels are in place. Then fully tighten all the screws.


Note: Poke the sea grass to find the screw hole. The screws go through these holes to secure the panels. See drawing opposite.





2. Attach parts 'E' & 'F' Side Panels to part 'A' real panel, assembly using 2 screws each side

Ensure that the handles are on the outsides, & that the lid securing chain fixings are near the back panel.




Issue date: 18/11/2009
Revision number

ASSEMBLY – STAGE TWO




Front / Lid assembly

3. Attach parts 'E' & 'F' Side panels to part 'C' Base Panel assembly using 1 screw each side



4. Attach part 'B' Front panel to part 'E' & 'F' side panels and part C base board



Finally fully tighten all screws.


Issue date: 18/11/2009
Revision number

ASSEMBLY – STAGE THREE




Final lid assembly

5. Attach Lid 'D' to chest assembly, by locating the hinge flaps together & then securing by pushing the 'Rods' in from both sides of the hinge.




6. Attach the chain on the lid & on the rear inside face of each side to the hook as shown.



Issue date:18/11/2009
Revision number

LARGE SEAGRASS CHEST

Assembly Instructions - Please keep for future reference | **875/7276**



Dimensions

Width - 85cm

Depth - 45cm

Height - 46cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts,call the **Customer Helpline:08456 400800**

ISSUE: 001 DATE: 05.29.13

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and fittings listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 pepole.
- Do not sit or stand on the product, this could cause damage.



- We do not recommend the use of power drill/ drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth. Do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Safety warning information


- To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.
- If parts are missing, broken or damaged or worn, stop use of this product until repairs are made & using factory authorized parts.
- Failure to follow these warnings could result in serious injury.
- Use this product only for storage 58kg at most.
- Do not use this chest unless all bolts, and screws are firmly secured.
- Do not put weight on the top of the lid over 22kg.

Components - Parts


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the components listed below


1 Top Panel 85*45cm




2 Front Panel 85*41cm




3 Back Panel 85*41cm




4 Left Panel 38*41cm



5 Right Panel 38*41cm



6 Bottom Panel 78.5*38cm



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A Screw Ø6*50mm  x16	B Allen key  x1	C Bolt Ø3*30mm  x4	

Assembly Instructions

NOTE: It would be useful to ask someone to help you assemble the chest.

Step 1

Attach left panel 4 and right panel 5 into bottom panel 6 using 2pcs screw A.




NOTE: All the screw holes are marked by cream washers and passed through by plastic loops.

- Do not overtighten screws and fittings.

Step 2


Attach back panel 3 into bottom panel 6, left panel 4 and right panel 5 using 7pcs screw A.



Assembly Instructions

Step 3

Attach front panel 2 into bottom panel 6, left panel 4 and right panel 5 using 7pcs screw A.




Step 4

• Connect top panel 1 to back panel 3 using 4pcs bolt C at the hinges.

• Connect the strings by pressing the hook of the string on top panel 1.

Assembly is complete.



If you need help or have damaged or missing parts,call the **Customer Helpline: 08456 400800**
Home Retailer Group, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, MK9 2NW