Components


Ⓐ 5 x Support Tube



Ⓑ 2 x Lower Side Frame




Ⓒ 2 x Upper Side Frame




Ⓓ 4 x Top Plastic Plug



Ⓔ 4 x Bottom Plastic Plug



Ⓕ 4 x Castor



Fittings


Ⓐ 10 x Screw



Ⓑ 2 x Screw




Ⓒ 1 x Tool



4-05

Chrome Tidy Rail

Simple Assembly Instructions - **Please keep for future reference**



IMPORTANT

1. *Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.*
2. *Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.*
3. *Take all the fittings out of the plastic bag and separate them into their groups.*
4. *Ensure you have enough space to lay out all the parts before assembly.*
5. *To avoid scratching it is recommended that you assemble the unit on a soft level surface.*

Assembly Instructions

Stage 1 – Fitting the Side Frame

NOTE: It would be useful to ask someone to help you at this stage.

1. Insert Lower Side Frame Ⓑ into Upper Side Frame Ⓒ.
   See fig. 1.

2. Use Screw Ⓑ to fix the Frames. Then press the Top Plastic Plugs Ⓓ and Bottom Plastic Plugs Ⓔ firmly into the ends of the Side Frames.
   See fig. 2.

3. Insert the Castors Ⓕ firmly into the unit and ensure they are well fitted.
   See fig. 3.

4. Use the same method as in fig. 1-3 to fix the other Side Frame.

5. Use Screws Ⓐ to fix Support Tubes Ⓐ onto the Side Frame.
   See fig. 4.




fig. 1




fig. 2




fig. 3




fig. 4

Assembly Instructions

Stage 2 – Finishing the Unit

1. Use Screws Ⓐ to fix the other Side Frame onto the unit.
   See fig. 5.

2. Carefully place the unit in the desired location.
   See fig. 6.

NOTE: Always make sure the unit is secure before use.





fig. 5


fig. 6

Care and Maintenance

Safety
To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.


Cleaning
As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting
From time to time please ensure there are no loose screws on the product.

Chrome Tidy Rail

Assembly Instructions - Please keep for future reference

875/8457



Dimensions

Width - 115cm
Depth - 43cm
Height - 168cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Issue 1 - 9/07/08

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do no stand or put weight on the product during assembly, this could cause damage.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit.
Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**


Please check you have all the fittings listed below




1 Support tube x 5



2 Lower side frame x 2



3 Upper side frame x 2



4 Castor x 4





5 Plastic plug x 4


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A 	B 	C 	D 
38mm Screw x 10	12mm Screw x 2	Tool x 1	Spanner x 1

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Insert the Eng plugs [5] into the top of the Upper side frame [3].

Fix the Castors [4] into the bottom of the Lower side frame [2] using Spanner Ⓓ.

Repeat the above processes for the second Side frame.

Note: Place the side frame gently and horizontally on the ground.




Step 2

Fix the Upper side frame [3] to the Lower side frame [2] using Screws Ⓑ.

Repeat the above process for the second Side frame.

Note: Place the side frame gently and horizontally on the ground.




Assembly Instructions

Step 3

Note: It would be useful to ask someone to help you at this stage.

Fix the Support tubes 1 onto the Side frame using Screws A.


Do not fully tighten the screws.



Step 4

Fix the Support tubes 1 onto the other side of the Side frame using Screws A.


Retighten all screws.



Assembly Instructions

Carefully place the tidy rail in the desired location.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**