IMPORTANT SAFETY INFORMATION & WARNINGS

BATTERY WARNINGS Do not attempt to replace the battery, open the device enclosure or disassemble your TIKKERS product. Doing so can result in a safety hazard • The integrated rechargeable battery cannot be removed or replaced • Substances within TIKKERS smartwatch battery may harm the environment or cause injury if handled or disposed of improperly • In the unlikely event of contact with battery acid, thoroughly flush the affected area with plenty of clean water and seek IMMEDIATE medical attention • When the battery is fully charged disconnect from charger, DO NOT exceed 2 hour charge time.

DEVICE WARNINGS This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures • Ensure your smartwatch correctly engages with the charging contacts • Before each use, please check the product for damage, do not use if the product is damaged • This is not a toy, children should not play with this product • Never attempt to open your smartwatch, this may result in danger • Protect the product from strong impacts, vibrations, direct sunlight and dirt • Do not place heavy objects on the product • Do not exert pressure on the product • Avoid strong magnetic fields e.g. loudspeakers • Salt and thermal water can lead to the corrosion of metal parts • Remove the product before using saunas as the temperature difference can cause condensation • Do not operate the product near heat sources e.g. radiators or other devices emitting heat. Do not cover the product during operation or charging • Never use the product on aeroplanes, in hospitals, service rooms, or near medical electronic systems. The wireless signals transmitted could impact the functionality of sensitive electronics • Do not use your TIKKERS product if the display is cracked • Do not expose your TIKKERS product to extremely high or low temperatures • Do not use abrasive cleaners to clean your TIKKERS product • Remove your TIKKERS product immediately if it feels warm or hot • Do not attempt to wear or operate your TIKKERS product whilst charging • Do not charge your TIKKERS product if wet • Do not check notifications or other applications on the products display while driving or in other situations where distractions could be hazardous. Always be aware of your surroundings when using TIKKERS products and services • Ensure your smartwatch is removed at regular intervals for gentle cleaning.

HEALTH WARNINGS TIKKERS smartwatches contain components that emit electromagnetic fields, with some of the models containing a magnetic charging dock, please be aware that these models contain magnets. These electromagnetic fields and magnets may interfere with medical devices, such as pacemakers and implanted defibrillators. Please consult your doctor and medical device manufacturer if you use any medical device before using a TIKKERS smartwatch • Your TIKKERS smartwatch will help calculate distances covered during activity. Please consult a doctor before starting new exercise regimes • TIKKERS smartwatches contain sensors to track your movement to closely estimate your activity, sleep etc. These close estimations are not always fully accurate • Some wearers may suffer skin irritation if the smartwatch is worn for prolonged periods, especially if you suffer from sensitive skin or have allergies. If you notice any irritation you should remove your smartwatch. To help prevent any irritation please ensure the smartwatch is removed regularly for cleaning & do not over-tighten on your wrist • We recommend you remove your smartwatch each day for gentle cleaning.

In the case of material damage or personal injury caused by incorrect handling or non-compliance with the safety instructions, no liability can be accepted by TIKKERS. If you have any questions or concerns, please contact us, you'll find our contact details on this leaflet.

DECLARATION OF CONFORMITY To view our declaration of conformity certification, please visit the Tikkers website : https://www.tikkers.co.uk/pages/declaration-of-conformity-certification

Manufactured by: Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham Business Park, Bickenhill Lane, Solihull, B37 7GN, UK.
EU Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.

TKQSG0222

TIKKERS

QUICK START GUIDE

Thank you for choosing a TIKKERS activity tracker! Your watch has a variety of features to get to know. This short guide will have you up and running in no time. To set up your activity tracker and download your full instructions, simply scan the QR code with your smartphone camera, or visit our website link below.

www.tikkers.co.uk/pages/activity-trackers

Our website is available 24/7, where you can find lots more information including full instructions, video guides, FAQs and much, much more!

If you'd like any assistance using your TIKKERS tracker or our App. please get in touch. We want you to get the very best from your tracker, we will always be happy to help!

You can contact our UK based customer service team Monday to Friday, 9AM to 4PM by phone or email.

Support@Tikkers.co.uk +44 (0) 121 524 1400

You'll find a variety of extra bands & chargers available for your activity tracker on our website!

Don't forget to follow us on social media for lots of fun stuff!

Tikkers.Official Tikkers.Official

TIKKERS.CO.UK

GETTING STARTED

To get started, you'll need to download our Tikkers App. You can scan the QR code below to take you straight to our App. (use your smartphone camera or QR code reader App.) Alternatively, search 'Tikkers' in your App. store.

CHARGING GUIDE

1. Remove the device from the band as shown below. Gently press from the back whilst holding the band securely.





2. Insert into the charging cradle with button facing forward.
3. Once the charger is switched on, the band will be activated automatically.
4. Please charge the band when it displays low battery.
5. A two hour charge time is sufficient to fully charge your activity tracker, please do not exceed a 2 hour charge period.

STEP COUNTER

Smartwatches use multiaxis inertial sensors called accelerometers to detect when the device is moving to measure steps. Some wrist actions can mimic the movement of a step and falsely record steps, so as with any smartwatch or tracker, the step count recorded each day should be used as a guide only.

GUARANTEE

Quality and style are at the heart of what we do. TIKKERS certifies this activity tracker is produced using premium materials and is fully tested before leaving our manufacturing centre.

Your activity tracker is guaranteed against any defective parts and construction for 12 months from the date of purchase. Your guarantee is only valid if you present your original receipt when returning the item. This guarantee provides you with rights in addition to your consumer statutory rights and therefore does not limit your statutory rights. Please note this guarantee does not cover lenses or bands, water penetration or batteries. Additionally, breakages caused by accident or maltreatment are not covered.

All products should be returned to:
PH Services, Precision House, Unit 4, Starley Way, Solihull, B37 7GN.

Please contact us before sending in your product and we will guide you through the process. Our contact details are on the front of this leaflet.

COMPATIBILITY

The TIKKERS App. is compatible with the following smartphones featuring Bluetooth 5.0. Please ensure the App. is the latest version & check for updates.

- Android (version 4.4 and above)
- Apple IOS (version 8.0 and above)

DISPOSAL OF GOODS

The crossed out wheelie bin symbol is to remind you that waste electrical products, batteries and accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility.

- Do not dispose of this product within household waste.
- Disposal your TIKKERS product and packaging should be done in accordance with your local regulations.