
Carbrini 4ft Folding Football Table

carbrini

Model No. 1070

Parts List





2 X Side Walls

2 X Goal Ends

2 X End Walls

2 X Table Support Braces

2 X Iron Cross Big Beam

2 X Iron Tube Leg

4 X Supporting Metal Pole

2 X Ball Return Boxes

2 X Slide scorers

8 X Rod Handle





8 X Rubber End Caps





16 X Bumper





16 X Plastic Washer





2 X One Man Rod (1Red/1Blue)





2 X Two Man Rod (1Red/1Blue)









(1Red/1Blue)





2 X Footballs





1 X Allen Key





1 X Allen Key






8 X Bolt(M6X1-3/4")











4 X Screw(T4X1-1/2")





6 X Screw(T4X12mm)





4 X Bolt(M6X28mm)



4 X Bolt(M6X51mm)



4 X Bolt(M6X29mm)





8 X Nut





16 X Washer











8 X Screw(#8X38mm)

Safety Information

- 1. Read instructions carefully before assembling the unit.
- 2. Check that you have all the parts following the list below and familiarise yourself with each part before proceeding.
- 3. Ensure you have enough space before assembly.
- 4. To avoid scratching it is recommended that you assemble the unit on a soft level surface.
- 5. Always "Lift" the table to move it as dragging across a floor can
- 6. Fitting: From time to time please ensure there are no loose screws on the product.



WARNING - CHOKING HAZARD This item contains small parts, not suitable for children under 3 years old.




This item is very heavy. A minimum of two persons should be used to assemble or manoeuvre the table.


This item must be assembled by an adult. Make sure table is assembled and secure before use.




Debut Sports & Leisure Ltd, Unit 1.9 Paintworks, Bath Road, Bristol BS4 3EH Spareparts helpline: 0870 112 1928 Email: helpline@clickspares.co.uk

ASSEMBLING YOUR 4FT FOOTBALL TABLE









Slide all the player poles in place in the colour order shown, make sure the opposite teams are facing each other towards the opposing goal (fig 3).









Now slide the table pitch (1) in place along the groove provided (fig 5).








Debut Sports & Leisure Ltd, Unit 1.9 Paintworks, Bath Road, Bristol BS4 3EH Spareparts helpline: 0870 112 1928 Email: helpline@clickspares.co.uk





Debut Sports & Leisure Ltd, Unit 1.9 Paintworks, Bath Road, Bristol BS4 3EH Spareparts helpline: 0870 112 1928 Email: helpline@clickspares.co.uk








Debut Sports & Leisure Ltd, Unit 1.9 Paintworks, Bath Road, Bristol BS4 3EH Spareparts helpline: 0870 112 1928 Email: helpline@clickspares.co.uk




Lock leg struts in place using bolts 28. (fig 11).





Using two adults carefully turn the table over and adjust the leg leveller if needed to create an even playing surface. Now attached the end goal boxes (9) to the table using screw 26. Attached the slide scorers (10) to the top of the goal boxes using screw 27 as shown. Finally cover the end of all the poles with the end caps and handles in the correct place. Tip: Follow the diagram below and start at the goal to prevent incorrect handle placement (fig 12).

You are ready the play!





Debut Sports & Leisure Ltd, Unit 1.9 Paintworks, Bath Road, Bristol BS4 3EH Spareparts helpline: 0870 112 1928 Email: helpline@clickspares.co.uk