











Carbrini 12 X 6 Premium Quality Goal Instructions






Model No.1223

Carbrini 12 X 6 Premium Quality Goal

Part List



How to use the connectors



Use the tube and connector together as illustrated.




WARNING
Choking Hazard
Not suitable for children under 3 years, as product contains small parts.




WARNING
A minimum of two people should be used to assemble the goal frame.

To be assembled & dismantled by an adult.
To be used on a flat grass surface
Check all buttons are firmly tight and the frame assembly is securely pegged to ground before use.
Do not leave outdoors in adverse weather conditions.
Do not climb or hang from cross bar.
Check regularly for wear and tear.
Discontinue use if any breakage is found.
Failure to do this may result in injury.
Keep away from fire.
Keep away from heat sources.

Step 1



Join the tubes together with connectors as illustrated.



Ensure that the tubes are used full into the connectors, with the buttons secured into the holes.

Spread net out and locate the two red tabs. Put the net (Part O) over the frame with the red tabs in the top left and right hand corners of the frame. (Step 10)

The seam of the net should follow the frame supports. Secure the net to the frame using the net clips (Part N) ensuring you space them out evenly over the whole frame. (See step 11)

Position the assembled frame and fix to the ground using the 4 steel pegs (Part P). Position around the frame base. (See steps 12, 13)

CAUTION:

Check regularly that pegs are secure. Loose pegs may cause injury. Care should be taken when using a mallet as misuse may cause injury.

