
MOSES BASKET - ASSEMBLY INSTRUCTIONS

YOUR COMPONENTS/ FITTINGS

PLEASE CHECK YOU HAVE THE FITTINGS SHOWN BELOW.

Please note: The quantities below are the correct amount to complete the assembly.



x 2 Screws x 2 Washers x 2 Wing Nuts x 2 Nyloc Nuts




x 2 Hood Runners
(to fit into the channels in the hood as shown)


STEP 1 - HOOD ASSEMBLY

Insert the hood runners (E) within the two channels shown in the hood diagram below.

There are channel openings at both ends.




SCREW POSITION





Screw should be positioned in the second hole down closest to the outside of the handle.

POSITION OF COMPONENTS




STEP 2 - INSERTING SCREW & WASHER






Place the attached screw (A) and washer (B) through the hole from the inside of the basket and hold in position. (See screw position diagram)

STEP 3 - INSERTING THE RUNNERS





Having located the screw with the washer attached from the inside of the basket, now attach the BACK runner E outside of the basket.



Then attatching the FRONT runner E on top of the BACK runner. It is essential that BACK runner is attached first, followed by the FRONT.

STEP 4 - ATTACHING WING NUT & NYLOC NUT





FINALLY ATTACH THE WING NUT AND LOCKING NYLOC NUT:
The locking Nyloc nut should be tightened with a pair of plyers so that it locks and cannot be undone using finger pressure.

Please note: if the hood of the moses basket does not stay up,tighten the wing nut slightly. The Nyloc nut is used for extra security to keep the wing nut in place.

STEP 5 - REPEAT PROCESS

Repeat process 2,3 & 4 to attach hood to the otherside of the basket.

WARNING: PLEASE MAKE SURE ALL FITTINGS ARE ACCOUNTED FOR AND THAT NOTHING IS LEFT IN THE BASKET, AS THESE COULD CREATE A SERIOUS HAZARD TO BABY.

PLEASE KEEP INSTRUCTIONS FOR FUTURE REFERENCE!

CL4124/CL4285 WHITE WAFFLE MOSES BASKET & FOLDING STAND

IMPORTANT

READ INSTRUCTIONS CAREFULLY AND KEEP THEM FOR FUTURE REFERENCE

WARNING: This product is only suitable for a child who cannot sit unaided, roll over and cannot push itself up on its hands or knees.
Maximum weight of the child 9 Kg.
Before picking up the Carrycot, make sure both handles are secure in the hand of the Carer.
Use only on firm, horizontal level & dry surface**.**
WARNING: Do not let other children play unattended near the carry cot.
WARNING: Do not use if any part is broken, torn or missing.
Use only replacement or approved parts from Dawson & Rodgers & Co Ltd.
WARNING: Maintaining a safe distance from the strong heat sources such as electric bar fires, gas fires, etc in the near vicinity of moses basket.
If the mattress is purchased separately, it shall fit well into the product and the depth from the top of the side of the product should not be less than 170mm when the mattress is in position of use.
The handles and the bottom should be inspected regularly for signs of damage & wear.
If the moses basket is intended to be used with a stand, then it should be checked that the stand is the appropriate size to accommodate the base of the moses basket. Base size min-max 700-835mm in length and 300-370mm in width

CLEANING INSTRUCTIONS

BASKET: Sponge lightly with warm water and mild detergent.
MATTRESS: If necessary wash by hand in warm water and mild detergent. Dry away from direct heat or sunlight. Do not tumble dry. Do not dry clean.
DRESSING: See care label on product.

Dispose of all packaging safely before use.Complies with BS EN 1466:2004

Dawson Rodgers & Co Ltd, Shenton Road, Sharston Industrial Estate, Wythenshawe, Manchester M22 4RW