

CASIO




W-735H-1AVEF

Specifications

- ⇒ Vibration Alarm
- ⇒ Daily Alarm
- ⇒ Stopwatch
- ⇒ 100M WR
- ⇒ LED Light
- ⇒ 10-Year Battery



Model variations may differ in appearance from the example above.

Stop Watch	1/100-sec accuracy	Press button C until you reach ST mode. Start and stop stopwatch using button D , reset stopwatch using button A .  <p>(a) Elapsed time measurement (b) Split time measurement (c) Split time and two finishes</p>
Alarm	Allows you to specify the hour, minutes, day and month of the alarm.	In Alarm Mode, Press B to change status of the daily alarm and hourly time signal. Follow display indicator in the sequence; 
Water Resistant	Suitable for bathing, swimming, and showering. not for diving.	Not suitable for swimming, snorkelling or diving. *Do not fully submerge for long periods of time.
Vibration Alarm	<p>To turn the vibration alarm on and off</p> <p>Vibration alarm on indicator</p>  <p>In the Timekeeping Mode, hold down (D) for about two seconds to toggle the Vibration Alarm between on (Vibration Alarm on indicator displayed) and off (indicator not displayed).</p> <ul style="list-style-type: none"> • The watch will vibrate when you toggle to on, and beep when you toggle to off. • Turning on the Vibration Alarm also disables the button operation tone. 	
LED Light	In any mode Press L to illuminate display	
10 Year Battery	Battery power lasts up to approximately ten-years without changing.	CASIO's advanced technology allows extended battery life for up to ten-years. All timekeeping modes and functions of the watch can be used continuously for up to ten-years without a battery change.