
DR8250320

Bergen SHELF PACK 120 x 200 x 53cm

Assembly Instructions Please keep for future reference 237/5805

hygena



Dimensions

Width - 57.7cm
Depth - 48.8cm
Height - 1.8cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit: **www.argos-support.co.uk**
or email: **Help@ClickSpares.co.uk** (quoting your original order number)
Alternatively, call the Spares Helpline on: **0370 112 1928**
For any other queries please contact the Customer Helpline on: **0345 640 2020**

Issue 3 - 05/11/15

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are tightend properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

For damaged or missing parts, please visit:
www.argos-support.co.uk or email: **Help@ClickSpares.co.uk**

Please check you have all the panels listed below



1 Horizontal
(57.7 x 48.8cm)
P1887




2 Shelf x 2
(57.7 x 48.8cm)
P1888

Components - Fittings


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete te assembly. In some cases more fittings may be supplied than are required.


1/1

A *FK1056*  Small locking screw x 6	B *FK1051*  Cam 20x12mm Expando housing x 6	C *FK1207*  Shelf support with fixinghole x 8
D *FK1309*  12,5mm Screw x 8		


Tools required




Phillips screwdriver
(medium & large)




Small hammer



Flatblade screwdriver
(medium)




Eye protection (when using a hammer or drill)



Scissors

Ruler - Use this ruler to help correctly identify the screws





The screws length is measured from the head to the point (30mm screw shown).


Assembly Instructions

Step 1

Insert the fittings


a:
change the place of one hanging-rail as shown.

a:



b:
Insert 6 small locking screws Ⓐ as shown.

b:



Assembly Instructions


Step 2

Inserting Horizontal

a: Push Cam Expando housing Ⓑ into the hole of the Horizontal [1].

b: Turn Horizontal [1] and lower it onto the small locking screws Ⓐ.

c: Tighten the Cams Ⓑ with a Philips screwdriver.



Assembly Instructions


Step 3

inserting shelves

a: Push shelf supports Ⓒ in hole as shown.

b: Position shelves 2 onto shelf supports Ⓒ and fix by screwing eight chipboardscrews Ⓓ through shelf supports Ⓒ into shelves 2.

a:



b:

