
Assembly & Operation Instructions


HOME

HOME MULTI-PURPOSE AIRER (9190210)

Pack Included



Tools required:




Drill

To Assemble

Align 1 x part B with hole in frame and push/click into place. Repeat with the other part B.


To Open


Release the retention clip and open airer to desired angle by turning locking wheels anti-clockwise to allow movement. Move to desired angle and turn locking wheels clockwise to lock in position.





Usage

On a wall - Fix mounting brackets (C) to a wall that is in good condition using an 8mm drill bit, drill, plugs (D) and screws (E). Brackets need to be 704mm apart. Slide side arms and raise to 90 degrees off the drying rack and fix into wall brackets. Use as one rack or change angle to 90 degrees to increase drying space.













On a radiator - slide side arms and raise to 90 degrees off the drying rack and fix over radiator. Use as one rack or change angle to 90 degrees to increase drying space.









Freestanding - open airer to desired angle, lock in position and place on floor.

Over the bath - open airer to desired angle, lock in position and place over the bath ensuring the support brackets (B) are located on the side of the bath.

Maximum loaded weight 5kg, evenly spaced or 1 wash load.

Storage and Care

When not in use it is suggested that you close this item and store safely away from children and pets. Clean with a damp cloth.

Warning

This is not a toy. Do not allow children to play with this product.

- For indoor use only
- Do not exceed the maximum loading weight


Customer Support

0345 640 2020

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: ⚠ Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.

Revision 2 - 7/10/09