
Adjustable Tidy Rail

Assembly Instructions - Please keep for future reference | 932/7502



Dimensions

Width - 109.5cm
Depth - 48.5cm
Height - 182cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Issue 1 - 22/03/11

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.
- Assemble the unit as close to its final position (in the same room) as possible.



- We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the panels listed below


1 Upper side support x 2 (105cm)



2 Lower side support x 2 (78.9cm)



3 Upper adjustable support x 1 (100cm)



4 Lower adjustable support x 1 (73.5cm)

5 Cross bar x 2 (104.2cm)

6 Adjustable hanging rail (short) x 1 (55cm)

7 Adjustable hanging rail (long) x 1 (58cm)

8 Bottom cross bar x 2 (104.5cm)


9 Leg tube x 2 (48cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A Plastic cap x 2 	**B** Plastic end sleeve x 4 	**C** Joint x 2 
D Adjustor x 1 	**E** 50mm Flat Hex. Screw x 10	**F** 50mm Hex. Socket Flat Screw x 2
G Allen key x 1 	**H** Spacer x 4 	

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Fitting the side support


a: Insert Plastic cap Ⓐ into Upper side support [1], then insert the other end of Upper side support [1] into Lower side support [2].

Repeat step **a:** to finish the other side support.




Fitting the adjustable support

b: Insert each Joint Ⓒ into the end of Upper adjustable support [3] and Lower adjustable support [4], then insert Upper adjustable support [3] into Lower adjustable support [4].




c: Insert Cross bar [5] through the Joint Ⓒ on the Adjustable support [3] & [4].



d: Use Flat hex. screw Ⓔ to connect Side support [1]&[2], Spacer Ⓗ, Cross bar [5],then tighten by Allen key Ⓖ.

Repeat step **d:** to finish the other side.




Assembly Instructions

Step 2


Fitting the leg section

a: Attach Plastic end sleeve Ⓑ into Leg tube [9], use Flat hex. screw Ⓔ to join Leg tube [9] with Bottom cross bar [8], then tighten by Allen key Ⓖ.




Finishing the Unit

b: Fitting the adjustable hanging rail. Insert Adjustor Ⓓ into Adjustable hanging rail [6], then insert Adjustable hanging rail [7] into Adjustable hanging rail [6].



Note: It would be useful to ask someone to help you at this stage.

c: Use Flat hex. screw Ⓔ to fix adjustable support with hanging rail [7], use Flat hex. screw Ⓔ to fix side support with hanging rail [6], then both tighten by Allen key Ⓖ. Use Hex. socket flat screw Ⓕ to fix the leg tubes with Lower side support [2], tighten by Allen key Ⓖ. Carefully put the Unit Upside.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**