


CHAD VALLEY 3 FT TABLE TOP FOOTBALL TABLE ASSEMBLY INSTRUCTION



Item number: 935/3514

If you have a problem with this product, we want to help. For immediate assistance, please phone: 0871 226 2034

Parts #1 #2 #3 #4 1/4"×1-1/8" Bolt 1/4" Washer Tool 1-1/2" Round head screw 20 pieces 20 pieces 1 piece 10 pieces #6 #5 #7 #8 7/8" Flat head screw 3/8"Round head screw Slide scorer Rod handle 4 pieces 8 pieces 2 pieces 8 pieces #9 #11 #10 #12 Rod end cap Playing field Side panel End panel 8 pieces 2 pieces 1 piece 2 pieces #14 #13 #15 #16 Leg A Leg B Playfield support brace Leg panel 1 piece 2 pieces 2 pieces 2 pieces #18 #19 #20 #17 1 Home players rod 2 Home players rod 3 Home players rod 4 Home players rod 1 piece 1 piece 1 piece 1 piece #22 #25 #21 2 Away players rod 1 Away players rod 3 Away players rod 4 Away players rod Soccer ball 1 piece 1 piece 1 piece 4 pieces 1 piece



WARNING: Choking Hazard--Toy contains small balls and/or small parts. Not for children under 3 years.

- -Caution! Adult assembly required.
- -Sharp point on screws; unpack and assemble with care. Keep small parts and polybag away from children during & after assembly. You will need a wrench and screwdriver (not included) to assemble.


IMPORTANT!

Please Keep Your Instructions. Before attempting assembly, please read through this instruction book to familiarize yourself with all the parts and assembly steps. We recommend that two adults assemble this game. Please refer to the Parts List above and be sure that all parts have been included.

CHAD VALLEY 3 FT TABLE TOP FOOTBALL TABLE


Step 1:

Carefully turn the side panel (#10) upside down and slide the home and away team rods (#17-#24) into the pre-drilled holes in the order shown in the diagram.



Step 2:


Slide the playing field (#12) upside down into the grooves of side panels (#10). Slide the player rods through the remaining side panel (#10).



CHAD VALLEY 3 FT TABLE TOP FOOTBALL TABLE


Step 3:

Secure the unit together by fixing the end panel (#11) to the side panel (#10) and the playing field (#12) using screws (#1) and washer (#2). Repeat at the other end of the table.




Step 4:

Using screw (#4) fix the playfield support brace (#13) between the side panels (#10).



CHAD VALLEY 3 FT TABLE TOP FOOTBALL TABLE

Step 5:



Step 6:

Carefully turn the table over and attach slide scorer (#7) to the table end via the pre-drilled holes at the end of the table using screw (#5).

Slide the rod handles (#8) onto the player rods and attach using screw (#6). Please make sure to secure the handles at the end of the rods with the pre-drilled holes.

Finally, add the end caps (#9) at the opposite end of the player rods

