
## WI47



## WATCH INSTRUCTIONS

For more information, or to view the Rotary watches collections please visit www.rotarywatches.com service@rotarywatches.com



## **B) OPERATION**

1) Pull out the crown to the first click.

2) Turn the crown clockwise until the previous day's date appears.

3) Pull out the crown to the second click when the second hand is at the 12 o'clock position.

4) Turn the crown until the desired date appears.

5) Turn the crown to set hour and minute hands.

(Check that AM / PM is set correctly.)

6) Push the crown back in to normal position. accordance with the time signal.

## Note:

\* The date will change gradually between 9:00 P.M. and 4:00 A.M. Therefore, do not set the date during this time period or the date may not change properly. If it is necessary to set the calendar during that time period, first change the time to any time outside it, set the date and then reset the correct time.



www.rotarywatches.com service@rotarywatches.com